



NexAIoT Co., Ltd.

IoT Automation Solutions Business Group

Industrial Automation System

CMC300-Fxx Series

User Manual



Preface

Copyright iv

Disclaimer iv

Acknowledgements iv

Regulatory Compliance Statements iv

Declaration of Conformity iv

RoHS Compliance vi

Warranty and RMA vii

Disclaimer viii

Safety Information ix

Installation Recommendations ix

Safety Precautions x

Technical Support and Assistance xi

Conventions Used in this Manual xi

Global Service Contact Information xii

Package Contents xiv

Ordering Information xv

Chapter 1: Product Introduction

Overview 1

Hardware Specifications 2

Knowing Your CMC300-Fxx Series 4

Mechanical Dimensions 5

 CMC300-F13 5

 CMC300-F2x 6

 CMC300-F0x 7

Chapter 2: Installation

Installation Environment 8

Installation Steps 8

Chapter 3: Jumpers and Connectors

Before You Begin 11

Precautions 11

Jumper Settings 12

Locations of the Jumpers and Connectors for the Main Board 13

Jumpers 14

 Clear CMOS 14

 AT/ATX Power Mode Select 14

Connector Pin Definitions 15

 External I/O Interfaces - Front Panel 15

 LAN1 and USB 3.0 Ports 15

 LAN2 and USB 2.0 Ports 16

 DVI-D Connector 17

 COM 1 Port 17

 24V DC Power Input 18

 External On/Off Control Port 18

 Internal Connectors 19

 Debug Port 19

 Battery Connector 19

 Audio HDA Pin Header 20





COM2 Connector20

SATA Connector 121

SATA Connector 221

SATA Power Connector 122

SATA Power Connector 222

FAN Connector23

Mini-PCIe Connector.....24

PCIe x8 Slot.....25

Chapter 4: BIOS Setup

About BIOS Setup26

When to Configure the BIOS.....26

Default Configuration27

Entering Setup27

Legends27

BIOS Setup Utility.....29

 Main29

 Advanced30

 Chipset.....34

 Security34

 Boot.....35

 Save & Exit35

Appendix A: Power Consumption



Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from NexAloT Co., Ltd.

Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from NexAloT Co., Ltd. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.nexaiot.com>. NexAloT shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

Acknowledgements

The CMC300-Fxx series is a trademark of NexAloT Co., Ltd. All other product names mentioned herein are registered trademarks of their respective owners.

Regulatory Compliance Statements

This section provides the FCC compliance statement for Class A devices and describes how to keep the system CE compliant.

Declaration of Conformity

FCC

This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

RoHS Compliance



NexAloT RoHS Environmental Policy and Status Update

NexAloT is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, NexAloT has established an engineering and manufacturing task force to implement the introduction of green products. The task force will ensure that we follow the standard NexAloT development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which NexAloT are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

How to recognize NexAloT RoHS Products?

For existing products where there are non-RoHS and RoHS versions, the suffix "(LF)" will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual NexAloT naming convention.

Warranty and RMA

NexAloT Warranty Period

NexAloT manufactures products that are new or equivalent to new in accordance with industry standard. NexAloT warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by NexAloT.

NexAloT Return Merchandise Authorization (RMA)

- Customers shall enclose the “NexAloT RMA Service Form” with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the “NexAloT RMA Service Form” for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, NexAloT is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as “Out of Warranty.”
- Any products returned by NexAloT to other locations besides the customers’ site will bear an extra charge and will be billed to the customer.

Repair Service Charges for Out-of-Warranty Products

NexAloT will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

System Level

- Component fee: NexAloT will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with NexAloT products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, NexAloT will return it to the customer without any charge.

Board Level

- Component fee: NexAloT will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, NexAloT will return it to the customer without any charge.

Disclaimer

Information of Product Connection

Terminal block is mating with Plug and suitable for 14-20AWG. Torque value 5-7 lb-in. Use Copper Conductors Only. The temperature rating of the input connection cable wire should be at least 60°C with plastic part higher than 75°C.

Liability Disclaimer

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.

Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

Technical Support and Assistance

1. For the most updated information of NexAloT products, visit NexAloT's website at www.nexaiot.com.
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
 - Product name and serial number
 - Detailed information of the peripheral devices
 - Detailed information of the installed software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wordings of the error messages

Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

Conventions Used in this Manual



Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



Caution:

Information to avoid damaging components or losing data.



Note:

Provides additional information to complete a task easily.

Global Service Contact Information

Headquarters

NEXCOM International Co., Ltd.

9F, No. 920, Chung-Cheng Rd.,
Zhonghe District, New Taipei City, 23586,
Taiwan, R.O.C.
Tel: +886-2-8226-7786
Fax: +886-2-8226-7782
www.nexcom.com

Asia

Taiwan

NexAIoT Headquarters

Industry 4.0 and Cloud Services

12F, No.922, Zhongzheng Rd.,
Zhonghe Dist., New Taipei City,
23586, Taiwan, R.O.C.
Tel: +886-2-8226-7796
Fax: +886-2-8226-7926
Email: sales@nexaiot.com
www.nexaiot.com

NexAIoT Co., Ltd.

Taichung Office

16F, No.250, Sec. 2, Chongde Rd.,
Beitun District,
Taichung City, 406, Taiwan, R.O.C.
Tel: +886-4-2249-1179
Fax: +886-4-2249-1172
Email: sales@nexaiot.com
www.nexaiot.com

NexCOBOT Taiwan Co., Ltd.

13F, No.916, Chung-Cheng Rd.,
Zhonghe District,
New Taipei City, 23586, Taiwan, R.O.C.
Tel: +886-2-8226-7786
Fax: +886-2-8226-7926
Email: sales@nexcobot.com
www.nexcobot.com

GreenBase Technology Corp.

13F, No.922, Chung-Cheng Rd.,
Zhonghe District,
New Taipei City, 23586, Taiwan, R.O.C.
Tel: +886-2-8226-7786
Fax: +886-2-8226-7900
Email: sales@nexcom.com.tw
www.nexcom.com.tw

EMBUX Technology Co., Ltd.

13F, No.916, Chung-Cheng Rd.,
Zhonghe District,
New Taipei City, 23586, Taiwan, R.O.C.
Tel: +886-2-8226-7786
Fax: +886-2-8226-7782
Email: sales@nexcom.com.tw
www.nexcom.com.tw

TMR Technology Corp.

13F, No.916, Chung-Cheng Rd.,
Zhonghe District,
New Taipei City, 23586, Taiwan, R.O.C.
Tel: +886-2-8226-7786
Fax: +886-2-8226-7782
Email: sales@nexcom.com.tw
www.nexcom.com.tw

China

NEXSEC Incorporated

5F, No.4, No.7 Fengxian Middle Rd.,
(Beike Industrial Park), Haidian District,
Beijing, 100094, China
Tel: +86-10-5704-2680
Fax: +86-10-5704-2681
Email: marketing@nexsec.cn
www.nexsec.cn

NEXCOM Shanghai

No.4, 16 Building,
Shanghai OMNI Tech & Science Park
No. 1699, Douhui Rd.,
Shanghai, 201108, China
Tel: +86-21-5278-5868
Fax: +86-21-3251-6358
Email: sales@nexcom.cn
www.nexcom.cn

NEXCOM Surveillance Technology Corp.

5F, Building C, ZhenHan Industrial Zone,
GanKeng Community, Buji Street,
LongGang District,
ShenZhen, 518112, China
Tel: +86-755-8364-7768
Fax: +86-755-8364-7738
Email: steveyang@nexcom.com.tw
www.nexcom.cn

NEXCOM United System Service

Room 603/604, Huiyinmingzun Plaza Bldg. 1,
No. 609, Yunlin East Rd.,
Shanghai, 200062, China
Tel: +86-21-5278-5868
Fax: +86-21-3251-6358
Email: renwang@nexcom.com.tw
www.nexcom.cn

NEXGOL Chongqing

1F, Building B4, Electronic 2nd Area,
(Phoenix Lake Industrial Park), Yongchuan Dist.,
Chongqing City, 402160, China
Tel: +86-23-4960-9080
Fax: +86-23-4966-5855
Email: sales@nexgol.com.cn
www.nexcobot.com/NexGOL

NexCOBOT China

Room 501, Building 1, Haichuang Building,
No.7 Qingyi Road, Guicheng Street,
Nanhai District, Foshan City,
Guangdong Province, 528314, China
Tel: +86-757-8625-7118
Email: sales@nexcobot.com
www.nexcobot.com.cn

Beijing NexGemo Technology Co.,Ltd.

5F, Gemotech Building, No.1, Development Rd.,
Changping International Information Industry Base,
Changping District,
Beijing, 102206, China
Tel: +86-10-8190-9328
Fax: +86-10-8190-9456
Email: sales@gemotech.cn
www.nexgemo.cn

Japan

NEXCOM Japan

9F, Tamachi Hara Bldg.,
4-11-5, Shiba Minato-ku,
Tokyo, 108-0014, Japan
Tel: +81-3-5419-7830
Fax: +81-3-5419-7832
Email: sales@nexcom-jp.com
www.nexcom-jp.com

America

USA NEXCOM USA

46665 Fremont Blvd.,
Fremont CA 94538, USA
Tel: +1-510-656-2248
Fax: +1-510-656-2158
Email: sales@nexcom.com
www.nexcomusa.com



Package Contents

Before continuing, verify that the package you received is complete. Your package should have the item listed in the table below.

Accessories

| Item | Description | Qty |
|------|--------------------------|-----|
| 1 | 3-pin Terminal Connector | 1 |
| 2 | Panel Mount Kit | 8 |



Ordering Information

The following information below provides ordering information for CMC300-Fxx series.


Barebone

- **CMC300-F03 (P/N: 10CM0030004X0)**
Cabinet mount controller fanless PC with Intel® Core™ i5-9500TE
2.2GHz
- **CMC300-F13 (P/N: 10CM0030005X0)**
Cabinet mount controller fanless PC with Intel® Core™ i5-9500TE
2.2GHz, and one PCIe x8 expansion slot
- **CMC300-F22 (P/N: 10CM0030001X0)**
Cabinet mount controller fanless PC with Intel® Core™ i7-9700TE
1.8GHz, and two PCIe x4 expansion slots
- **CMC300-F23 (P/N: 10CM0030002X0)**
Cabinet mount controller fanless PC with Intel® Core™ i5-9500TE
2.2GHz, and two PCIe x4 expansion slots

Optional

- **DDR4 DRAM 16GB (P/N: 72BGM16G07H00)**
- **DDR4 DRAM 32GB (P/N: 72BGM32G02H00)**

Overview

CMC300-F13**CMC300-F2x****CMC300-F0x**

Key Features

- Fanless system design (CMC300-F13, CMC300-F2x)
- Fanless system design with slim form factor (CMC300-F0x)
- Intel® Xeon® E-2278GEL and 8th & 9th generation Intel® Core™ i7/i5/i3 LGA socket type processors
- 2 x Gigabit Ethernet
- 2 x USB 2.0, 2 x USB 3.0, 1 x COM RS232/422/485
- IP65 protection on the outside heatsink
- 1 x DVI-D display output
- 2 x DDR4 up to 64GB
- 1 x Mini-PCIe for storage device
- 2 x Easy-access 2.5" SSD trays
- Support power input 24 VDC

Hardware Specifications

CPU Support

- Support Intel® Xeon® E-2278GEL
- Support 8th & 9th generation Intel® Core™ i7/i5/i3 LGA socket type:
 - Intel® Core™ Core i3-8100T, i5-8500T, i7-8700T
 - Intel® Core™ Core i3-9100TE, i5-9500TE, i7-9700TE
- Support up to TDP 35W CPU

PCH

- Intel® C246 PCH

Main Memory

- 2 x DDR4 2400/2666 SO-DIMM sockets, support up to 64GB with non-ECC and un-buffered
- Support ECC with Intel® Xeon® processor

I/O Interface Status LEDs

- Power
- SATA (SSD)

I/O Interface - Front

- DC power input connector: 3-pin Phoenix Contact terminal blocks
- COM: 1 x RS232/422/485
- Display: 1 x DVI-D port
- Ethernet: 2 x RJ45
 - LAN: 1 x Intel® I219-LM PHY LAN and 1 x Intel® I210-IT Gigabit LAN
 - Ethernet interface: 10/100/1000 Mbps
 - Support wake up on LAN

- 2 x USB 2.0 ports
- 2 x USB 3.0 ports
- 2-pin remote power on/off
- 1 x Easy-access RTC battery socket

Storage Device

- 2 x Easy-access 2.5" SSD trays
- 1 x Mini-PCIe slot for storage

Expansion (CMC300-F2x Only)

- Two PCIe x4 expansion slots from PCIe x8 riser card

Power Requirements

- DC power input:
 - Input voltage: 18VDC -5% to 24VDC +10%, 7.5A
 - Reverse polarity protection

Environment

- Operating temperature:
 - 0°C to 55°C with natural convection
 - 0°C to 60°C with mild forced airflow
- Operating humidity support 10%~90% relative humidity, non-condensing
- Vibration protection w/ HDD condition:
 - Random: 0.5Grms @ 5~500 Hz, IEC60068-2-64
 - Sinusoidal: 0.5Grms @ 5~500 Hz, IEC60068-2-64



Dimensions

CMC300-F13 / CMC300-F2x

- Dimension: 330mm x 275mm x 116.2mm
- Weight: 6kg

CMC300-F0x

- Dimension: 330mm x 275mm x 62.7mm
- Weight: 5.7kg

Construction

- Aluminum extrusion heat sink and iron nickel plating housing
- Back cover with reserved RAID card heatsink hole
- IP65 protection for the outside heatsink


Certifications

- CE (EN61000-6-2/EN61000-6-4)
- FCC Class A

OS Support List

- Windows 10 64-bit

Knowing Your CMC300-Fxx Series



The image shown above uses CMC300-F2x as an example. The I/O descriptions for other devices in the same series are the same.

2.5" Storage Drive Bay

Two removable storage drive bays used to install 2.5" HDD/SSDs.

Power Switch

Press to power-on or power-off the system.

LED Indicators

Indicates the power status and storage drive activity of the system.

LAN

Used to connect the system to a local area network.

USB 3.0

USB 3.0 ports to connect the system with USB 3.0/2.0 devices.

USB 2.0

USB 2.0 ports to connect the system with USB 2.0/1.1 devices.

DVI-D

Used to connect a DVI-D interface display.

Remote On/Off Switch (Default: No function; Optional: Please refer to page 19)

Used to connect a remote to power on/off the system.

COM


DB9 port used to connect RS232/RS422/RS485 compatible devices.

DC Input


Used to plug a DC power cord.

Mechanical Dimensions


CMC300-F13



CMC300-F2x



CMC300-F0x






Installation Environment


- This device is an open type, intended to be installed in an industrial control panel or an enclosure. Indoor use and pollution degree II. Operating altitude is up to 2000m.

Installation Steps


1. Cut a hole in the enclosure for the specified cut-out size of 320 x 265mm and a thickness ranging from 1 to 2.5mm, based on the device dimensions of 318 x 263mm.



2. Secure the panel mount kits (x8) to the rear panel of the device using the smaller screws provided in the accessory package, following the image shown below.





3. Insert the device through the opening.



4. Tighten the device using the larger screws provided in the accessory package.

5. Assembly completed.



This chapter describes how to set the jumpers and connectors on the CMC300-Fxx series motherboard.

Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
 - A Philips screwdriver
 - A flat-tipped screwdriver
 - A set of jewelers screwdrivers
 - A grounding strap
 - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short



Locations of the Jumpers and Connectors for the Main Board

The figure below is the top view of the main board used in the CMC300-Fxx Series. It shows the locations of the jumpers and connectors.





Jumpers

Clear CMOS

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: CLRCMOS1



| Pin | Settings |
|--------|-----------|
| 1-2 On | N/A |
| 2-3 On | RTC Reset |

1-2 On: default

AT/ATX Power Mode Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP2



| Pin | Settings |
|--------|----------|
| 1-2 On | AT |
| 2-3 On | ATX |

2-3 On: default


Connector Pin Definitions

External I/O Interfaces - Front Panel

LAN1 and USB 3.0 Ports

Connector type: RJ45 port with LEDs and dual USB 3.0 ports

Connector location: CON1A (USB) and CON1B (LAN1)



| Act | Status |
|-----------------|---------------|
| Flashing Yellow | Data activity |
| Off | No activity |

| Link | Status |
|---------------|----------------------|
| Steady Green | 1G network link |
| Steady Orange | 100Mbps network link |
| Off | 10Mbps or no link |

USB


| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | +5V | 2 | USB2_N |
| 3 | USB2_P | 4 | GND |
| 5 | USB3_RXN | 6 | USB3_RXP |
| 7 | GND | 8 | USB3_TXN |
| 9 | USB3_TXP | 10 | +5V |
| 11 | USB2_N | 12 | USB2_P |
| 13 | GND | 14 | USB3_RXN |
| 15 | USB3_RXP | 16 | GND |
| 17 | USB3_TXN | 18 | USB3_TXP |

LAN1

| Pin | Definition | Pin | Definition |
|------|--------------|------|--------------|
| 19 | +0V9_LAN | 20 | LAN_MDI0P |
| 21 | LAN_MDI0N | 22 | LAN_MDI1P |
| 23 | LAN_MDI1N | 24 | LAN_MDI2P |
| 25 | LAN_MDI2N | 26 | LAN_MDI3P |
| 27 | LAN_MDI3N | 28 | GND |
| LED1 | +3VSB | LED2 | LAN_LED_ACT# |
| LED3 | LAN_LED_100# | LED4 | LAN_LED_1G# |

LAN2 and USB 2.0 Ports

Connector type: RJ45 port with LEDs and dual USB 2.0 ports
Connector location: CN6A (USB) and CN6B (LAN2)



| Act | Status |
|-----------------|---------------|
| Flashing Yellow | Data activity |
| Off | No activity |

| Link | Status |
|---------------|----------------------|
| Steady Green | 1G network link |
| Steady Orange | 100Mbps network link |
| Off | 10Mbps or no link |

USB


| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | +5V | 2 | USB2_N |
| 3 | USB2_P | 4 | GND |
| 5 | +5V | 6 | USB2_N |
| 7 | USB2_P | 8 | GND |

LAN2

| Pin | Definition | Pin | Definition |
|-----|--------------|-----|---------------|
| 9 | +1V5_LAN | 10 | LAN_MDI0P |
| 11 | LAN_MDI0N | 12 | LAN_MDI1P |
| 13 | LAN_MDI1N | 14 | LAN_MDI2P |
| 15 | LAN_MDI2N | 16 | LAN_MDI3P |
| 17 | LAN_MDI3N | 18 | GND |
| 19 | LAN_LINK_1G# | 20 | LAN_LINK_100# |
| 21 | LAN_LED_ACT# | 22 | +3VSB |

DVI-D Connector


Connector type: 24-pin D-Sub, 2.0mm-M-180 (DVI)
Connector location: CON2



| Pin | Definition | Pin | Definition |
|-----|-------------|-----|-------------|
| 1 | DVI_DATA2_N | 2 | DVI_DATA2_P |
| 3 | GND | 4 | NC |
| 5 | NC | 6 | DVI_CLK |
| 7 | DVI_DAT | 8 | NC |
| 9 | DVI_DATA1_N | 10 | DVI_DATA1_P |
| 11 | GND | 12 | NC |
| 13 | NC | 14 | +5V |
| 15 | GND | 16 | DVI_HPD |
| 17 | DVI_DATA0_N | 18 | DVI_DATA0_P |
| 19 | GND | 20 | NC |
| 21 | NC | 22 | NC |
| 23 | DVI_CLK_P | 24 | DVI_CLK_N |

COM 1 Port


Connector type: DB-9 port, 9-pin D-Sub
Connector location: CN7



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | DCD# | 2 | RXD |
| 3 | TXD | 4 | DTR# |
| 5 | GND | 6 | DSR# |
| 7 | RTS# | 8 | CTS# |
| 9 | RI# | | |
| MH1 | GND | MH2 | GND |

24V DC Power Input

Connector type: Phoenix Contact 1x3 3-pin terminal block
Connector location: PW1



| Pin | Definition |
|-----|-------------|
| 1 | VIN |
| 2 | VSS |
| 3 | CHASSIS_GND |




Information of Product Connection

Terminal block is mating with Plug and suitable for 14-20AWG. Torque value 5-7 lb-in. Use Copper Conductors Only. The temperature rating of the input connection cable wire should be at least 60°C with plastic part higher than 75°C

External On/Off Control Port

Connector type: Phoenix Contact 1x2 2-pin terminal block
Connector location: J6



| Pin | Definition |
|-----|-------------|
| 1 | IGNITION |
| 2 | CHASSIS_GND |

Electrical Characteristics and Behavior

PC_ON signal: 24V DC static input with an internal pull-down resistor. The input is protected against overvoltage and reverse polarity.

Control Logic

- If Pin 1 (IGNITION) is Not Connected (NC) and remains NC for at least 0.5 seconds, the PC system will power on.
- If Pin 1 (IGNITION) is connected to +24V DC and remains at +24V DC for at least 0.5 seconds, the PC system will shut down.



Internal Connectors

Debug Port

Connector type: 1x10 10-pin header, 1.0mm pitch
Connector location: J4



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | GND | 2 | PLTRST# |
| 3 | LPC_CLK | 4 | LPC_FRAME# |
| 5 | LPC_AD3 | 6 | LPC_AD2 |
| 7 | LPC_AD1 | 8 | LPC_ADO |
| 9 | +3V3 | 10 | +3V3 |
| MH1 | GND | MH2 | GND |

Battery Connector

Connector type: 1x2 2-pin header, 1.25mm pitch
Connector location: J3




| Pin | Definition |
|-----|------------|
| 1 | VCC3 |
| 2 | GND |



Audio HDA Pin Header

Connector type: 2x5 10-pin header, 2.54mm pitch
Connector location: JHDA1



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | HDA_SDO | 2 | +5V |
| 3 | HDA_RST# | 4 | GND |
| 5 | HDA_SYNC | 6 | +12V |
| 7 | HDA_SDI0 | 8 | HDA_SDI1 |
| 9 | HDA_CLK | 10 | NC |

COM2 Connector

Connector type: 1x10 10-pin header, 1.0mm pitch
Connector location: J5




| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | DCD# | 2 | RXD |
| 3 | TXD | 4 | DTR# |
| 5 | GND | 6 | DSR# |
| 7 | RTS# | 8 | CTS# |
| 9 | RI# | 10 | GND |
| MH1 | GND | MH2 | GND |



SATA Connector 1


Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)
Connector location: CN4



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | GND | 2 | SATA_TXP1 |
| 3 | SATA_TXN1 | 4 | GND |
| 5 | SATA_RXN1 | 6 | SATA_RXP1 |
| 7 | GND | | |
| MH1 | GND | MH2 | GND |

SATA Connector 2

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)
Connector location: CN3




| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1 | GND | 2 | SATA_TXP2 |
| 3 | SATA_TXN2 | 4 | GND |
| 5 | SATA_RXN2 | 6 | SATA_RXP2 |
| 7 | GND | | |
| MH1 | GND | MH2 | GND |



SATA Power Connector 1

Connector type: 1x2 2-pin header, 2.5mm pitch
Connector location: J1



| Pin | Definition |
|-----|------------|
| 1 | VCC5 |
| 2 | GND |

SATA Power Connector 2


Connector type: 1x2 2-pin header, 2.5mm pitch
Connector location: J2




| Pin | Definition |
|-----|------------|
| 1 | VCC5 |
| 2 | GND |

FAN Connector

Connector type: 1x4 4-pin Wafer, 2.54mm pitch
Connector location: CN2




| Pin | Definition |
|-----|-------------|
| 1 | GND |
| 2 | +12V |
| 3 | FAN_TAC |
| 4 | FAN_CONTROL |



Note: Turn the 4th DIP switch of SW2 from off to on, this way the Remote On/Off Switch Connector can be used for support. However, it must be connected to a single cut switch and not connected to tact switch.

Mini-PCle Connector

Connector location: CN5




| Pin | Definition | Pin | Definition |
|-----|------------|-----|-------------|
| 1 | PCIE_WAKE# | 2 | 3VSB |
| 3 | NC | 4 | GND |
| 5 | NC | 6 | 1.5V |
| 7 | CLKREQ# | 8 | NC |
| 9 | GND | 10 | NC |
| 11 | PCIE_CLK# | 12 | NC |
| 13 | PCIE_CLK | 14 | NC |
| 15 | GND | 16 | NC |
| 17 | NC | 18 | GND |
| 19 | NC | 20 | DISABLE# |
| 21 | GND | 22 | PCIE_RESET# |
| 23 | PCIE_RXN | 24 | 3VSB |
| 25 | PCIE_RXP | 26 | GND |

| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 27 | GND | 28 | 1.5V |
| 29 | GND | 30 | SMB_CLK |
| 31 | PCIE_TXN | 32 | SMB_DATA |
| 33 | PCIE_TXP | 34 | GND |
| 35 | GND | 36 | USB_N |
| 37 | GND | 38 | USB_P |
| 39 | 3VSB | 40 | GND |
| 41 | 3VSB | 42 | NC |
| 43 | GND | 44 | NC |
| 45 | NC | 46 | NC |
| 47 | NC | 48 | 1.5V |
| 49 | NC | 50 | GND |
| 51 | NC | 52 | 3VSB |



PCIe x8 Slot

Connector type: PCIe x8 Slot
Connector location: CN1



| Pin | Definition | Pin | Definition |
|-----|-------------|-----|---------------|
| A1 | PCIE_PRSNT1 | B1 | +12V |
| A2 | +12V | B2 | +12V |
| A3 | +12V | B3 | +12V |
| A4 | GND | B4 | GND |
| A5 | PEG_CLK_P10 | B5 | PCIE_SMB_CLK |
| A6 | PEG_CLK_N10 | B6 | PCIE_SMB_DAT |
| A7 | NC | B7 | GND |
| A8 | NC | B8 | +3V3 |
| A9 | +3V3 | B9 | NC |
| A10 | +3V3 | B10 | +3VSB |
| A11 | PLT_RST# | B11 | PCIE_WAKE# |
| A12 | GND | B12 | NC |
| A13 | PEG_CLK_P11 | B13 | GND |
| A14 | PEG_CLK_N11 | B14 | PEG_TXP8 |
| A15 | GND | B15 | PEG_TXN8 |
| A16 | PEG_RXP8 | B16 | GND |
| A17 | PEG_RXN8 | B17 | PCIE_PRSNT2_1 |
| A18 | GND | B18 | GND |
| A19 | NC | B19 | PEG_TXP9 |
| A20 | GND | B20 | PEG_TXN9 |
| A21 | PEG_RXP9 | B21 | GND |

| Pin | Definition | Pin | Definition |
|-----|------------|-----|---------------|
| A22 | PEG_RXN9 | B22 | GND |
| A23 | GND | B23 | PEG_TXP10 |
| A24 | GND | B24 | PEG_TXN10 |
| A25 | PEG_RXP10 | B25 | GND |
| A26 | PEG_RXN10 | B26 | GND |
| A27 | GND | B27 | PEG_TXP11 |
| A28 | GND | B28 | PEG_TXN11 |
| A29 | PEG_RXP11 | B29 | GND |
| A30 | PEG_RXN11 | B30 | NC |
| A31 | GND | B31 | PCIE_PRSNT2_2 |
| A32 | NC | B32 | GND |
| A33 | NC | B33 | PEG_TXP12 |
| A34 | GND | B34 | PEG_TXN12 |
| A35 | PEG_RXP12 | B35 | GND |
| A36 | PEG_RXN12 | B36 | GND |
| A37 | GND | B37 | PEG_TXP13 |
| A38 | GND | B38 | PEG_TXN13 |
| A39 | PEG_RXP13 | B39 | GND |
| A40 | PEG_RXN13 | B40 | GND |
| A41 | GND | B41 | PEG_TXP14 |
| A42 | GND | B42 | PEG_TXN14 |
| A43 | PEG_RXP14 | B43 | GND |
| A44 | PEG_RXN14 | B44 | GND |
| A45 | GND | B45 | PEG_TXP15 |
| A46 | GND | B46 | PEG_TXN15 |
| A47 | PEG_RXP15 | B47 | GND |
| A48 | PEG_RXN15 | B48 | PCIE_PRSNT2_3 |
| A49 | GND | B49 | GND |



This chapter describes how to use the BIOS setup program for the CMC300-Fxx series. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the NexAloT website at www.nexaiot.com.

About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure items such as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.

Default Configuration


Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

Entering Setup














When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing allows you to enter Setup.

Press the  key to enter Setup:


Legends

| Key | Function |
|---|--|
|   | Moves the highlight left or right to select a menu. |
|   | Moves the highlight up or down between sub-menus or fields. |
|  | Exits the BIOS Setup Utility. |
|  | Scrolls forward through the values or options of the highlighted field. |
|  | Scrolls backward through the values or options of the highlighted field. |
|  | Selects a field. |
|  | Displays General Help. |
|  | Load previous values. |
|  | Load optimized default values. |
|  | Saves and exits the Setup program. |
|  | Press <Enter> to enter the highlighted sub-menu. |


Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

Submenu


When “▶” appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .

BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 2005 to 2099.

System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.



Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.



Setting incorrect field values may cause the system to malfunction.

Aptio Setup Utility - Copyright (C) 2021 American Megatrends, Inc.

MainAdvancedChipsetSecurityBootSave & Exit

▶ CPU Configuration

▶ Power & Performance

▶ AMT Configuration

▶ ACPI Settings

▶ IT8786 Super IO Configuration

▶ Hardware Monitor

▶ USB Configuration

▶ Network Stack Configuration

CPU Configuration Parameters

←→: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2021 American Megatrends, Inc.

CPU Configuration

This section displays the information of the CPU installed.

Aptio Setup Utility - Copyright (C) 2021 American Megatrends, Inc.

Advanced

CPU Configuration

| | |
|----------------------|-------------------------|
| Type | Intel(R) Core(TM) |
| ID | i7-9700TE CPU @ 1.80GHz |
| Speed | 0x906ED |
| L1 Data Cache | 1800 MHz |
| L1 Instruction Cache | 32 KB x 8 |
| L2 Cache | 32 KB x 8 |
| L3 Cache | 256 KB x 8 |
| L4 Cache | 12 MB |
| VMX | N/A |
| SMX/TXT | Supported |
| | Supported |

←→: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2021 American Megatrends, Inc.

NEXIOT

Copyright © 2025 NexAloT Co., Ltd. All Rights Reserved.

30

CMC300-Fxx Series User Manual

ACPI Settings

This section is used to configure ACPI settings.



Enable Hibernation


Enables or disables system ability to hibernate (OS/S4 Sleep State). This option may not be effective with some OS.

ACPI Sleep State

Select the highest ACPI sleep state the system will enter when the suspend button is pressed. The options are Suspend Disabled and S3 (Suspend to RAM).

IT8786 Super IO Configuration

This section is used to configure the serial ports.



Super IO Chip

Displays the Super I/O chip used on the board.

Serial Port 1 Configuration

This section is used to configure serial port 1.



Serial Port

Enables or disables the serial port.

Onboard Serial Port Mode


Select this to change the serial port mode to RS232, RS422, RS485 or RS485 Auto.

Terminal 120 Ohm

Enables or disables serial port terminal resistance.

Hardware Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



CPU temperature

Detects and displays the current CPU temperature.

System temperature


Detects and displays the current system temperature.

Vcore to +5V

Detects and displays the output voltages.

USB Configuration

This section is used to configure the USB.



XHCI Hand-off

This is a workaround for OSs that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver respectively.

USB Mass Storage Driver Support

Enables or disables USB mass storage driver support.

USB transfer time-out

The time-out value for control, bulk, and Interrupt transfers.

Device reset time-out

Selects the USB mass storage device’s start unit command timeout.


Device power-up delay

Maximum time the value will take before it properly reports itself to the Host Controller. “Auto” uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.



Chipset

This section gives you functions to configure the system based on the specific features of the chipset. The chipset manages bus speeds and access to system memory resources.



SATA Controller(s)

Enables or disables the SATA controller.

SATA Mode Selection

Configures the SATA mode. The options are AHCI and Intel RST Premium.

SATA Test Mode

Enables or disables SATA test mode.

Aggressive LPM Support

Enables or disables PCH to aggressively enter link power state.

Security



Administrator Password


Select this to reconfigure the administrator's password.

User Password

Select this to reconfigure the user's password.



Boot



Setup Prompt Timeout

Configures the number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.

Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

Boot Option Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.

Save & Exit



Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes and Reset

To exit the setup utility and reset without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.



| CRB | Net Name | | | | | | | | | | |
|--------------------------|----------|------|-------|------|--------|-------|---------|------|------|------|----------------|
| Voltage Chipset | Voltage | 12V | 5V | 5V | 3.3V | 3.3V | 1.05V | 1.2V | 1.5V | 1.8V | Subtotal Power |
| | Net Name | +12V | +5VSB | +5V | +3VSB | +3V3 | +1V05SB | +1V2 | +1V5 | +1V8 | |
| Coffee lake-S (35W) | | | | | | | 0.23 | | | | |
| PCH H Q370 | | | | | 2.1 | | 8.1 | | | | |
| DDR4 SO-DIMM x 2 | | | | | | | | | | | |
| CH7517A | | | | | | 0.1 | | 0.2 | | | |
| PTN3360 | | | | | | 0.1 | | | | | |
| I219LM | | | | | 0.5 | | | | | | |
| I211-AT | | | | | 0.5 | | | | | | |
| SIO IT8786 | | | | 0.5 | 0.1 | 0.2 | | | | 0.1 | |
| ALC886 | | | | 0.1 | | 0.1 | | | | | |
| Mini-PCIe | | | | | 2.75 | | | | 0.5 | | |
| USB3 x 2 | | | 1.8 | | | | | | | | |
| USB2 x 2 | | | 1 | | | | | | | | |
| SATA x 2 | | | | 3 | | | | | | | |
| COM (RS232/RS422/RS485) | | | | 0.35 | | | | | | | |
| PCIe x8 Slot | | 3.1 | | | 0.6 | 5 | | | | | |
| Fan | | 1 | | | | | | | | | |
| System Total Current (A) | | 4.1 | 2.8 | 3.95 | 6.55 | 5.5 | 8.33 | 0.2 | 0.5 | 0.1 | |
| System Total Watt (W) | | 49.2 | 14 | 19.8 | 21.615 | 18.15 | 8.7465 | 0.24 | 0.75 | 0.18 | |



| CRB | Net Name | | | | | | | | | |
|--------------------------|----------|--------|------|----------|--------|-------|--------|-------|--------|----------------|
| Voltage Chipset | Voltage | 1.8V | 2.5V | 0.6V | 1.2V | 0.95V | 1.05V | 1.52V | 1.52V | Subtotal Power |
| | Net Name | +1V8SB | VPP | VDDQ_VTT | VDDQ | VCCIO | VCCSA | VCCGT | VCORE | |
| Coffee lake-S (35W) | | | | | 3.43 | 6.4 | 11.1 | 35 | 66 | |
| PCH H Q370 | | 0.5 | | | | | | | | |
| DDR4 SO-DIMM x 2 | | | 2 | 1 | 6 | | | | | |
| CH7517A | | | | | | | | | | |
| PTN3360 | | | | | | | | | | |
| I219LM | | | | | | | | | | |
| I211-AT | | | | | | | | | | |
| SIO IT8786 | | | | | | | | | | |
| ALC886 | | | | | | | | | | |
| Mini-PCIe | | | | | | | | | | |
| USB3 x 2 | | | | | | | | | | |
| USB2 x 2 | | | | | | | | | | |
| SATA x 2 | | | | | | | | | | |
| COM (RS232/RS422/RS485) | | | | | | | | | | |
| PCIe x8 Slot | | | | | | | | | | |
| Fan | | | | | | | | | | |
| System Total Current (A) | | 0.5 | 2 | 1 | 9.43 | 6.4 | 11.1 | 35 | 66 | |
| System Total Watt (W) | | 0.9 | 2 | 0.6 | 11.316 | 6.08 | 16.872 | 53.2 | 100.32 | |