



**NEXCOM International Co., Ltd.**

# **Network and Communication Solutions**

## **Network Security Appliance**

### **NSA 7131**

#### User Manual

# CONTENTS

## Preface

Copyright .....	iv
Disclaimer .....	iv
Acknowledgements .....	iv
Regulatory Compliance Statements .....	iv
Declaration of Conformity .....	iv
RoHS Compliance .....	v
Warranty and RMA .....	vi
Safety Information .....	viii
Installation Recommendations .....	viii
Safety Precautions .....	ix
Technical Support and Assistance .....	x
Conventions Used in this Manual .....	x
Global Service Contact Information .....	xi
Package Contents .....	xiii
Ordering Information .....	xiv

## Chapter 1: Product Introduction

Overview .....	1
Key Features .....	1
Hardware Specifications .....	2
Knowing Your NSA 7131 .....	3
Front Panel .....	3
Rear Panel .....	4

## Chapter 2: Jumpers and Connectors

Before You Begin .....	5
Precautions .....	5
Jumper Settings .....	6
Locations of the Jumpers and Connectors .....	7
Connector Pin Definitions .....	8
Internal Connectors .....	8
VGA Connector .....	8
SATA Connectors .....	8
USB 2.0 Header (Reserved) .....	9
LCM Header .....	9
CPU Fan Connector .....	10
ATX 4-pin Connector (Reserved) .....	10
USB 3.0 Box Header .....	11
8-pin ATX Power Connectors .....	11
24-pin ATX Power Connector .....	12
COM Port Header (Reserved) .....	12
GPIO Pin Header (Reserved) .....	13
PMBUS Header .....	13
PSU TTL Header .....	14
PCIe Slots .....	15
Block Diagram .....	17

## Chapter 3: System Setup

Installing a CompactFlash (CF) Card .....	18
Installing a CPU.....	19
Installing a DIMM Memory Module.....	21

## Chapter 4: BIOS Setup

About BIOS Setup.....	22
When to Configure the BIOS.....	22
Default Configuration .....	23
Entering Setup .....	23
Legends.....	23
BIOS Setup Utility.....	25
Main .....	25
Advanced .....	26
Intel RC Setup .....	36
Security .....	47
Boot.....	48
Save & Exit .....	49

# PREFACE

## Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from NEXCOM International Co., Ltd.

## Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from NEXCOM International Co., Ltd. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.nexcom.com>. NEXCOM shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

## Acknowledgements

NSA 7131 is a trademark of NEXCOM International Co., Ltd. All other product names mentioned herein are registered trademarks of their respective owners.

## Regulatory Compliance Statements

This section provides the FCC compliance statement for Class A devices and describes how to keep the system CE compliant.

## Declaration of Conformity

### FCC

This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

### CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

## RoHS Compliance



### **NEXCOM RoHS Environmental Policy and Status Update**

NEXCOM is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, NEXCOM has established an engineering and manufacturing task force in to implement the introduction of green products. The task force will ensure that we follow the standard NEXCOM development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which NEXCOM are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

### **How to recognize NEXCOM RoHS Products?**

For existing products where there are non-RoHS and RoHS versions, the suffix "(LF)" will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual NEXCOM naming convention.

## Warranty and RMA

### NEXCOM Warranty Period

NEXCOM manufactures products that are new or equivalent to new in accordance with industry standard. NEXCOM warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by NEXCOM. HCP series products (Blade Server) which are manufactured by NEXCOM are covered by a three year warranty period.

### NEXCOM Return Merchandise Authorization (RMA)

- Customers shall enclose the “NEXCOM RMA Service Form” with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the “NEXCOM RMA Service Form” for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, NEXCOM is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as “Out of Warranty.”
- Any products returned by NEXCOM to other locations besides the customers’ site will bear an extra charge and will be billed to the customer.

### Repair Service Charges for Out-of-Warranty Products

NEXCOM will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

### Repair Service Charges for Out-of-Warranty Products

NEXCOM will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

### System Level

- Component fee: NEXCOM will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with NEXCOM products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

### Board Level

- Component fee: NEXCOM will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

## Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

## Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

## Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

## Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.



## Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection to protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by skilled person.
14. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped and damaged.
  - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. **CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.**

“ATTENTION: Risque d'explosion si la batterie est remplacée par un type incorrect. Mettre au rebus les batteries usagées selon les instructions.”
18. This equipment is not suitable for use in locations where children are likely to be present.

Cet équipement ne convient pas à une utilisation dans des lieux pouvant accueillir des enfants.
19. Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.

Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.
20. Use certified and rated 3.3Vdc Laser Class I for Optical Transceiver product.

## Technical Support and Assistance

1. For the most updated information of NEXCOM products, visit NEXCOM's website at [www.nexcom.com](http://www.nexcom.com).
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
  - Product name and serial number
  - Detailed information of the peripheral devices
  - Detailed information of the installed software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wordings of the error messages

### Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.
3. CompactFlash: Turn off the unit's power before inserting or removing a CompactFlash storage card.

## Conventions Used in this Manual



### Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



### Caution:

Information to avoid damaging components or losing data.



### Note:

Provides additional information to complete a task easily.

## Global Service Contact Information

### Headquarters

#### **NEXCOM International Co., Ltd.**

9F, No. 920, Chung-Cheng Rd.,  
ZhongHe District, New Taipei City, 23586,  
Taiwan, R.O.C.

Tel: +886-2-8226-7786

Fax: +886-2-8226-7782

www.nexcom.com

### Asia

#### Taiwan

#### **NexAIoT Co., Ltd.**

#### **Taipei Office**

13F, No.920, Chung-Cheng Rd.,  
ZhongHe District,  
New Taipei City, 23586, Taiwan, R.O.C.

Tel: +886-2-8226-7796

Fax: +886-2-8226-7792

Email: sales@nexcom.com.tw

www.nexcom.com.tw

#### **NexAIoT Co., Ltd.**

#### **Taichung Office**

16F, No.250, Sec. 2, Chongde Rd.,  
Beitun Dist.,

Taichung City 406, R.O.C.

Tel: +886-4-2249-1179

Fax: +886-4-2249-1172

Email: sales@nexcom.com.tw

www.nexcom.com.tw

#### **NexCOBOT Taiwan Co., Ltd.**

13F, No.916, Chung-Cheng Rd.,  
ZhongHe District,  
New Taipei City, 23586, Taiwan, R.O.C.

Tel: +886-2-8226-7796

Fax: +886-2-8226-7792

Email: sales@nexcom.com.tw

www.nexcom.com.tw

#### **GreenBase Technology Corp.**

13F, No.922, Chung-Cheng Rd.,  
Zhonghe Dist.,  
New Taipei City, 23586, Taiwan, R.O.C.

Tel: +886-2-8226-7786

Fax: +886-2-8226-7900

Email: sales@nexcom.com.tw

www.nexcom.com.tw

### China

#### **NEXSEC Incorporated**

Floor 5, No.4, No.7 fengxian middle Rd.,  
(Beike Industrial Park), Haidian District,  
Beijing, 100094, China

Tel: +86-10-5704-2680

Fax: +86-10-5704-2681

Email: sales@nexcom.cn

www.nexcom.cn

**NEXCOM Shanghai**

Room 603/604, Huiyinmingzun Plaza Bldg., 1,  
No. 609, Yunlin East Rd.,  
Shanghai, 200062, China  
Tel: +86-21-5278-5868  
Fax: +86-21-3251-6358  
Email: sales@nexcom.cn  
www.nexcom.cn

**NEXCOM Surveillance Technology Corp.**

Floor 5, Building C, ZhenHan Industrial Zone,  
GanKeng Community, Buji Street,  
LongGang District,  
ShenZhen, 518112, China  
Tel: +86-755-8364-7768  
Fax: +86-755-8364-7738  
Email: steveyang@nexcom.com.tw  
www.nexcom.cn

**NEXCOM United System Service**

Room 603/604, Huiyinmingzun Plaza Bldg. 1,  
No. 609, Yunlin East Rd.,  
Shanghai, 200062, China  
Tel: +86-21-5278-5868  
Fax: +86-21-3251-6358  
Email: renwang@nexcom.com.tw  
www.nexcom.cn

**NEXGOL**

1st Floor, Building B4, Electronic 2nd Area,  
(Phoenix Lake Industrial Park), Yongchuan Dist.,  
Chongqing City, 402160, China  
Tel: +86-23-4960-9080  
Fax: +86-23-4966-5855  
Email: sales@nexcobot.com  
www.nexgol.com/NexGoL

**Beijing NexGemo Technology Co.,Ltd.**

5th Floor, Gemotech Building, No.1, Development Rd.,  
Changping International Information Industry Base,  
Changping District,  
Beijing, 102206, China  
Tel: +86-10-8190-9399  
Fax: +86-10-8190-9456

**Japan****NEXCOM Japan**

9F, Tamachi Hara Bldg.,  
4-11-5, Shiba Minato-ku,  
Tokyo, 108-0014, Japan  
Tel: +81-3-5419-7830  
Fax: +81-3-5419-7832  
Email: sales@nexcom-jp.com  
www.nexcom-jp.com

**Europe****United Kingdom  
NEXCOM EUROPE**

10 Vincent Avenue,  
Crownhill Business Centre,  
Milton Keynes, Buckinghamshire  
MK8 0AB, United Kingdom  
Tel: +44-1908-267121  
Fax: +44-1908-262042  
Email: sales.uk@nexcom.eu  
www.nexcom.eu

**America  
USA****NEXCOM USA**

2883 Bayview Drive,  
Fremont CA 94538, USA  
Tel: +1-510-656-2248  
Fax: +1-510-656-2158  
Email: sales@nexcom.com  
www.nexcom.com

## Package Contents

Before continuing, verify that the NSA 7131 package that you received is complete. Your package should have all the items listed in the following table.

Item	Part Number	Name	Description	Qty
1	19S00713132X0	NSA 7131 ASSY		1
2	5044440031X00	Rubber Foot Kang Yang:RF20-5-4P	19.8x18x5.0mm	4
3	6012200052X00	PE Zipper Bag #8	170x240mm, w/China RoHS Symbol	1
4	6012200053X00	PE Zipper Bag #3	100x70mm, w/China RoHS Symbol	1
5	6023309081X00	Cable EDI:232091081804-RS	COM Port. DB9 Female to RJ45 8P8C L:1800mm	1
6	50311F0109X00	Flat Head Screw Long Fei:F6#32Tx5 Nylok Black	F6#32Tx5 Black Nylok	16
7	50311F0162X00	Round Head Screw GW/Washer Long Fei	P4x8 iso/w NI	1
8	5040150001X00	NSA 7135 AL Handle VER:A Panadvance	78x58x8mm	1
9	6014605510X00	Outside Carton Label for NSA 7131 VER:A Label Jet	60x60mm ART Paper	1

## Ordering Information

The following information below provides ordering information for NSA 7131.

### Barebone

#### NSA 7131 (P/N: 10S00713132X0)

2U Intel® Xeon® E5-2600 v3 PCH C612, with LCM, 4 x swappable 3.5" HDD tray, 3 x swappable system fans, 4 x LAN module (NI/NX series) bays, 550W PSU

Model	P/N Controller	Interface	Type	Port Number	Bypass/Segment	Expansion Slot	Location Slot
<b>NX 140F</b>	10S20140F01X0	XL710-BM1	PCIe x8	4 SFP+	None	None	All Slot
<b>NX 142F</b>	10S20142F01X0	XL710-BM1	PCIe x8	4 SFP+	2 bypass	None	All Slot
<b>NX 120F</b>	10S20120F00X0	X710-BM2	PCIe x8	2 SFP+	None	One	All Slot
<b>NI 140F</b>	10SK000NI02X0	i350AM4x1	PCIe x8	4 SFP	None	None	All Slot
<b>NI 180F</b>	10S10180F01X0	i350AM4x2	PCIe x8	8 SFP	None	One	All Slot
<b>NI 142C</b>	10SK000NI03X0	i350AM4x1	PCIe x8	4 Copper	2 bypass	None	All Slot
<b>NI 180C</b>	10S10180C01X0	i350AM4x2	PCIe x8	8 Copper	None	None	All Slot
<b>NI 184C</b>	10S10184C01X0	i350AM4x2	PCIe x8	8 Copper	4 bypass	None	All Slot
<b>NI 142F</b>	10S10142F01X0	i350AM4x1	PCIe x8	4 SFP	2 bypass	None	All Slot
<b>NI 121F</b>	10S10121F01X0	i350AM2x1	PCIe x8	2 SFP	1 bypass	None	All Slot
<b>NI 140C</b>	10S10140C01X0	i350AM4x1	PCIe x8	4 Copper	None	None	All Slot

# CHAPTER 1: PRODUCT INTRODUCTION

## Overview



## Key Features

- Dual Intel® Xeon® processor E5-2600 v4/v3 product family
- Support DDR4 1866/2133 ECC & REG
- Support 4 x 3.5" swappable HDD bays
- Support LCD module
- Four LAN module slots

## Hardware Specifications

### Main Board

- NSB7131
- Intel® Xeon® processor E5-2600 v4/v3 product family
- Intel® Wellsburg C612 PCH

### Main Memory

- 8 x DDR4 1866/2133 DIMM sockets, up to 512GB ECC & REG SDRAM max. 256GB

### LAN Features

- Swappable LAN modules
- Support Intel® i350/Intel® XL710 copper/fiber ports
- Support 10/100/1000/10G link speed
- LAN bypass
  - \* Please see LAN module list information

### I/O Interface-Front

- 1 x Management port (LAN chip: Intel® i210)
- 2 x USB 2.0 ports
- 1 x RJ45 type console port
- 4 x PCIe Gen.3 LAN module slots (x8, x8, x4, x4)

### Devices

- 1x onboard CF card socket

### Power Input

- 550W 1+1 CRPS redundant power supply

### Chassis Dimensions

- Chassis dimension: 550mm x 438mm x 88mm
- Carton dimension: 767mm x 60mm x 242mm

### Weight

- Without packing: 14.045kg
- With packing: 19.04kg


### Certifications

- CE approval
- FCC Class A
- UL



# Knowing Your NSA 7131

## Front Panel



### HDD Bays

Four 3.5" HDD swappable bays.

### LAN Module Slots

Four LAN module slots.

### LED Indicators

Indicates the power status and storage drive activity of the system.

### Console Port

Used to connect RJ45 type console port.

### USB Ports

Used to connect USB 2.0/1.1 devices.


### Management LAN Ports

2 LAN ports used for managing the system.

### Reset Button

Press to restart the system.

## Rear Panel



### Power Switch

Press to power-on or power-off the system.

### AC Power Sockets

Dual redundant power supply sockets, plug an AC power cord here before turning on the system.

## CHAPTER 2: JUMPERS AND CONNECTORS

This chapter describes how to set the jumpers and connectors on the NSA 7131 motherboard.

### Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
  - A Philips screwdriver
  - A flat-tipped screwdriver
  - A set of jewelers screwdrivers
  - A grounding strap
  - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

### Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

## Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short



# Locations of the Jumpers and Connectors

The figure below shows the location of the jumpers and connectors.




## Connector Pin Definitions

### Internal Connectors

#### VGA Connector

Connector type: 2x8 16-pin header, 2.0mm pitch

Connector location: VGACONN1




Pin	Definition	Pin	Definition
1	DACROA_B	2	DACGOA_B
3	DACBOA_B	4	NC
5	GND	6	GND
7	GND	8	GND
9	VGA_VCC	10	GND
11	NC	12	DDC_DATAO_B
13	AHSYNCO_B	14	AVSYNCO_B
15	DDC_CLKO_B	16	NC

#### SATA Connectors

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)

Connector location: SATA1 to SATA8



Pin	Definition	Pin	Definition
1	GND	2	TXP
3	TXN	4	GND
5	RXN	6	RXP
7	GND		

## USB 2.0 Header (Reserved)

Connector type: 1x6 6-pin header, 2.0mm pitch  
Connector location: J4



Pin	Definition	Pin	Definition
1	5V	2	DN2
3	DP2	4	DN3
5	DP3	6	GND

## LCM Header

Connector type: 1x6 6-pin header, 2.0mm pitch  
Connector location: J6




Pin	Definition	Pin	Definition
1	TX	2	RX
3	GND	4	5V
5	LED_KR_N	6	LED_KG_N

## CPU Fan Connector

Connector type: 1x4 4-pin wafer

Connector location: FAN1



Pin	Definition	Pin	Definition
1	GND	2	P12V_CPU
3	FAN_TACH	4	FAN_PWM

## ATX 4-pin Connector (Reserved)

Connector type: 1x4 4-pin header, 5.08mm pitch

Connector location: CON4, CON5, CON6 and CON7




Pin	Definition	Pin	Definition
1	P12V	2	GND
3	GND	4	P5V



## USB 3.0 Box Header

Connector type: 2x10 20-pin header, 2.0mm pitch

Connector location: CN9




Pin	Definition	Pin	Definition
1	PV5_USB01_C	2	USB2_L_DN1
3	USB2_L_DP1	4	GND
5	USB3_L_RX_N2	6	USB3_L_RX_P2
7	GND	8	USB3_L_TX_N2
9	USB3_L_TX_P2	10	GND
11	USB2_L_DP0	12	USB2_L_DN0
13	GND	14	USB3_L_TX_P1
15	USB3_L_TX_N1	16	GND
17	USB3_L_RX_P1	18	USB3_L_RX_N1
19	PV5_USB01_C	20	NC

## 8-pin ATX Power Connectors

Connector type: 2x4 8-pin boxed header, 4.2mm pitch

Connector location: CON1 and CON2




Pin	Definition	Pin	Definition
1	GND	2	GND
3	GND	4	GND
5	P12V	6	P12V
7	P12V	8	P12V

## 24-pin ATX Power Connector

Connector type: 2x12 24-pin boxed header, 4.2mm pitch

Connector location: CON1



Pin	Definition	Pin	Definition
1	ATX_P3V3	2	ATX_P3V3
3	GND	4	P5V
5	GND	6	P5V
7	GND	8	PW-OK
9	P5VSB	10	P12V
11	P12V	12	ATX_P3V3
13	ATX_P3V3	14	-12V
15	GND	16	PS-ON
17	GND	18	GND
19	GND	20	RES/-5V
21	P5V	22	P5V
23	P5V	24	GND

## COM Port Header (Reserved)

Connector type: 2x5 10-pin header, 2.0mm pitch

Connector location: CN1




Pin	Definition	Pin	Definition
1	SP_DCD2	2	SP_RXD2
3	SP_TXD2	4	SP_DTR2
5	GND	6	SP_DSR2
7	SP_RTS2	8	SP_CTS2
9	SP_RI2	10	GND

## GPIO Pin Header (Reserved)

Connector type: 2x5 10-pin header, 2.0mm pitch

Connector location: JP1



Pin	Definition	Pin	Definition
1	P5V	2	GND
3	SIO_GP32	4	SIO_GP06
5	SIO_GP03	6	SIO_GP07
7	SIO_GP04	8	SIO_GP76
9	SIO_GP05	10	SIO_GP77

## PMBUS Header

Connector type: 1x5 5-pin header, 2.54mm pitch

Connector location: JPSMI1



Pin	Definition	Pin	Definition
1	PMBUS CLK	2	PMBUS DATA
3	PMBUS ALERT#(Reserve)	4	GND
5	NC		

## PSU TTL Header

Connector type: 1x3 3-pin header, 2.0mm pitch


Connector location: JP18



Pin	Definition
1	PSU_status1
2	PSU_status2
3	GND

## PCIe Slots

Connector location: JP14, JP15, JP16 and JP17




Pin	Definition	Pin	Definition
A1	GND	B1	12V
A2	12V	B2	12V
A3	12V	B3	12V
A4	GND	B4	GND
A5	NC	B5	SMBCLK
A6	NC	B6	SMBDATA
A7	NC	B7	GND
A8	NC	B8	3.3V
A9	3.3V	B9	NC
A10	3.3V	B10	P3V3AUX
A11	PRSNT#	B11	WAKE#
A12	GND	B12	BYPASS_GATE Enable
A13	CLK_P	B13	GND
A14	CLK_N	B14	TX0P
A15	GND	B15	TX0N
A16	RX0P	B16	GND

Pin	Definition	Pin	Definition
A17	RX0N	B17	NC
A18	GND	B18	GND
A19	BYPASS_A Enable	B19	TX1P
A20	GND	B20	TX1N
A21	RX1P	B21	GND
A22	RX1N	B22	GND
A23	GND	B23	TX2P
A24	GND	B24	TX2N
A25	RX2P	B25	GND
A26	RX2N	B26	GND
A27	GND	B27	TX3P
A28	GND	B28	TX3N
A29	RX3P	B29	GND
A30	RX3N	B30	BYPASS_B Enable
A31	GND	B31	NC
A32	BYPASS_C Enable	B32	GND

Pin	Definition	Pin	Definition
A33	BYPASS_D Enable	B33	TX4P
A34	GND	B34	TX4N
A35	RX4P	B35	GND
A36	RX4N	B36	GND
A37	GND	B37	TX5P
A38	GND	B38	TX5N
A39	RX5P	B39	GND
A40	RX5N	B40	GND
A41	GND	B41	TX6P
A42	GND	B42	TX6N
A43	RX6P	B43	GND
A44	RX6N	B44	GND
A45	GND	B45	TX7P
A46	GND	B46	TX7N
A47	RX7P	B47	GND
A48	RX7N	B48	NC
A49	GND	B49	GND


# Block Diagram




# CHAPTER 3: SYSTEM SETUP

## Installing a CompactFlash (CF) Card

1. With the chassis cover removed, locate the CF slot on the motherboard.
2. Insert the CF module until it is completely seated into the slot.



CF Slot




CF Module




## Installing a CPU



1. Locate the CPU socket on the motherboard.




2. Unlock the socket by pushing the two load levers down, moving them sideways until they are released from the retention tabs; then lift the load levers up and remove the CPU protective cap.



3. Insert the CPU into the socket. The triangular edge on the CPU must align with the corner of the CPU socket shown on the photo.



4. Close the load plate and then hook the load levers under the retention tabs.




Do not force the CPU into the socket. Forcing the CPU into the socket may bend the pins and damage the CPU.




- Handle the CPU by its edges and avoid touching the pins.
- The CPU will fit in only one orientation and can easily be inserted without exerting any force.

## Installing a DIMM Memory Module


1. Locate the DIMM sockets on the motherboard.




2. Release the locks on the DIMM sockets.



3. Insert the module into the socket at an 90 degree angle. Apply firm even pressure to each end of the module until it slips into the socket.



4. While pushing the module into position, the lock will close automatically.



# CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for the NSA 7131. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the NEXCOM website at [www.nexcom.com.tw](http://www.nexcom.com.tw).

## About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

## When to Configure the BIOS

- This program should be executed under the following conditions:
  - When changing the system configuration
  - When a configuration error is detected by the system and you are prompted to make changes to the setup program
  - When resetting the system clock
  - When redefining the communication ports to prevent any conflicts
  - When making changes to the Power Management configuration
  - When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.

## Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.












## Entering Setup

When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing  allows you to enter Setup.


## Legends

Key	Function
	Moves the highlight left or right to select a menu.
	Moves the highlight up or down between sub-menu or fields.
	Exits the BIOS Setup Utility.
	Scrolls forward through the values or options of the highlighted field.
	Scrolls backward through the values or options of the highlighted field.
	Selects a field.
	Displays General Help.
	Load previous values.
	Load optimized default values.
	Saves and resets the system.
	Press <Enter> to enter the highlighted sub-menu


## Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

## Submenu

When “▶” appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .

## BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

### Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



### Access Level

Displays the access level of the current user in the BIOS.

### System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1999 to 2099.

### System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

## Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.




Setting incorrect field values may cause the system to malfunction.



## NCT6776 Super IO Configuration

This section is used to configure the I/O functions supported by the onboard Super I/O chip.



### Super IO Chip

Displays the Super I/O chip used on the board.

### Serial Port 1 Configuration

Configuration settings for serial port 1.

### Serial Port 2 Configuration

Configuration settings for serial port 2.



## Serial Port 1 Configuration

This section is used to configure serial port 1.



### Serial Port


Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

## Serial Port 2 Configuration

This section is used to configure serial port 2.



### Serial Port


Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

## Hardware Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



### CPU temperature, THR1 and THR2 temperature

Detects and displays the current CPU, THR1 and THR2 temperature.

### CPU Fan Speed to CN6 Fan Speed


Detects and displays the current CPU Fan, CN2, CN3, CN4, CN5 and CN6 speed.

### VCORE to P12V

Detects and displays the output voltages.

## AST SEC Super IO Configuration

This section is used to configure the I/O functions supported by the onboard AST SEC Super I/O chip.



### Serial Port 2 Configuration

Configuration settings for serial port 2.

## Serial Port 2 Configuration

This section is used to configure serial port 2.



### Serial Port

Enables or disables the serial port.

### Change Settings

Selects an optimal setting for the Super IO device.

## Serial Port Console Redirection

This section is used to configure the serial port that will be used for console redirection.



### Console Redirection

Enables or disables the console redirection.

## Console Redirection Settings (COM0 to COM2)

Specifies how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.



### Terminal Type

- ANSI Extended ASCII character set.
- VT100 ASCII character set.
- VT100+ Extends VT100 to support color, function keys, etc.
- VT-UTF8 Uses UTF8 encoding to map Unicode characters onto 1 or more bytes.

### Data Bits

The options are 7 and 8.

### Bits Per Second

Selects the serial port transmission speed. The speed must match the other side. Long or noisy lines may require a lower speed.

### Parity

A parity bit can be sent with the data bits to detect some transmission errors.

- Even Parity bit is 0 if the number of 1's in the data bits is even.
- Odd Parity bit is 0 if number of 1's in the data bits is odd.

### Stop Bits

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

### Flow Control

Flow control can prevent data loss from buffer overflow. When sending data and the receiving buffers are full, a "stop" signal can be sent to stop the data flow.

### VT-UTF8 Combo Key Support

Enables or disables VT-UTF8 combination key support for ANSI/VT100 terminals.

### Recorder Mode

When this field is enabled, only text will be sent. This is to capture the terminal data.

### Resolution 100x31

Enables or disables extended terminal resolution.

### Legacy OS Redirection

Selects the number of rows and columns that support redirection.

### Putty KeyPad

Selects the Putty keyboard emulation type.

### Redirection After BIOS

The settings specify if BootLoader is selected, then Legacy console redirection is disabled before booting to Legacy OS. Default value is Always Enable which means Legacy Console Redirection is enabled for Legacy OS.

## Serial Port for Out-of-Band Management

Aptio Setup Utility - Copyright (C) 2017 American Megatrends, Inc.		
Advanced		
Out-of-Band Mgmt Port	[COM3]	Microsoft Windows Emergency Management Services (EMS) allows for remote management of a Windows Server OS through a serial port.
Terminal Type	[VT-UTF8]	
Bits per second	[115200]	
Flow Control	[None]	
Data Bits	8	
Parity	None	
Stop Bits	1	
		→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.17.1249. Copyright (C) 2017 American Megatrends, Inc.		

### Out-of-Band Mgmt Port

Configures the out-of-band management port. Microsoft Windows Emergency Management Services (EMS) allows for remote management of a Windows Server OS via a serial port.

### Terminal Type

- ANSI Extended ASCII character set.
- VT100 ASCII character set.
- VT100+ Extends VT100 to support color, function keys, etc.
- VT-UTF8 Uses UTF8 encoding to map Unicode characters onto 1 or more bytes.


### Bits Per Second

Selects the serial port transmission speed. The speed must match the other side. Long or noisy lines may require a lower speed.

### Flow Control

Flow control can prevent data loss from buffer overflow. When sending data and the receiving buffers are full, a “stop” signal can be sent to stop the data flow.

## Legacy Console Redirection Settings



### Legacy Serial Redirection

Configures a COM port to display redirection of legacy OS and legacy OPROM messages.

## PCI Subsystem Settings

This section is used to configure the PCI.



### Above 4G Decoding

Enables or disables decoding of 64-bit devices in 4G address space.

### SR-IOV Support

Enables or disables SR-IOV support.

## PCI Express Settings



### Relaxed Ordering

Enables or disables the PCI Express device's relaxed ordering.

### Extended Tag

When this function is enabled, it allows a device to use 8-bit tag field as a request.

### No Snoop


Enables or disables the PCI Express device's no snoop option.

### Maximum Payload

Selects the maximum TLP payload size of the PCI Express devices.

## Network Stack Configuration

This section is used to configure the network stack.




### Network Stack

Enables or disables UEFI network stack.

## CSM Configuration

This section is used to configure the compatibility support module features.



### CSM Support

This field is used to enable or disable CSM support, if Auto option is selected, based on OS, CSM will be enabled or disabled automatically.

### Network

Enables or disables the boot option for legacy network devices.

### Storage

Enables or disables the boot option for legacy storage devices.

### Video

Enables or disables the boot option for legacy video devices.

### Other PCI devices

Enables or disables the boot option for legacy PCI devices.



## USB Configuration

This section is used to configure the USB.



### Legacy USB Support

Enable Enables Legacy USB.

Auto Disables support for Legacy when no USB devices are connected.

Disable Keeps USB devices available only for EFI applications.

### XHCI Hand-off

This is a workaround for OSs that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver.

### EHCI Hand-Off

This is a workaround for OSs that does not support EHCI hand-off. The EHCI ownership change should be claimed by the EHCI driver.

### USB Mass Storage Driver

Enables or disables USB mass storage device driver support.

### Port 60/64 Emulation

Enables the 60h/64h I/O port emulation. You must enable this to fully support USB keyboard legacy for non-USB OSes.

### USB Transfer Time-out

The time-out value for control, bulk, and Interrupt transfers.

### Device Reset Time-out

Selects the USB mass storage device's start unit command timeout.

### Device Power-up Delay

Maximum time the value will take before it properly reports itself to the Host Controller. "Auto" uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

### Mass Storage Devices


Configures the mass storage device emulation type. AUTO enumerates devices according to their media format. Optical drives are emulated as CDROM, drives with no media will be emulated according to a drive type.

## Intel RC Setup

This section is used to configure the processor and chipset settings.



## Processor Configuration



### Hyper-Threading [ALL]

Enables or disables hyper-threading technology.

### Execute Disable Bit

When set to Disabled, it will force the XD feature flag to always return to 0.

### Enable Intel® TXT Support

Enables or disables Intel TXT support.

### VMX

Enables or disables Virtual Machine Extensions.


### Enable SMX

Enables or disables Secure Mode Extensions.

### Hardware Prefetcher

Enables or disables the MLC streamer prefetcher.


## Per-Socket Configuration



### CPU Socket 0 Configuration

Processor settings for the CPU on socket 0.

## CPU Socket 0 Configuration



### Cores Enabled

Configures the number of cores to enable. 0 means all cores.

### IoT Cfg Cbo Bitmap

Configures the bit to enable IOT/OCLA.

## Memory Configuration




### Memory Frequency

Configures the maximum frequency of the memory. Do not select Reserved.

## Memory Topology

Detects and displays the information on the memory installed.




## I/O Configuration



### EV DFX Features

Enables or disables the DFX Lock Bits to remain clear.

## IIO Configuration



### IOU2 (IIO PCIe Port 1)

Port Bifurcation settings for IOU 2.

### IOU0 (IIO PCIe Port 2)

Port Bifurcation settings for IOU 0.

### IOU1 (IIO PCIe Port 3)

Port Bifurcation settings for IOU 1.

### No PCIe Port Active

Configures the workaround solution for ECO when the PCIe ports are not active.

### IIO0 Redriver Control

Configures the redriver options for IIO0.

## Socket 0 PcieD00F0 - Port 0/DMI



### Link Speed

Configures the link speed of the PCIe port.

### Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

### PCI-E Port DeEmphasis

Configures the level of the PCIe port de-emphasis.

## Socket 0 PcieD01F0 - Port 1A to Socket 0 PcieD03F2 - Port 3C



### PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

### PCI-E Port Link

Enables or disables link training of the PCIe port.

### Link Speed

Configures the link speed of the PCIe port.


### Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

### PCI-E Port DeEmphasis

Configures the level of the PCIe port de-emphasis.


## I/O General Configuration



### I/O IOAPIC

Enables or disables I/O Advanced Power Interface Configuration (I/OAPIC) for I/O 0.

## Intel VT for Directed I/O (VT-d)




### Intel VT for Directed I/O

Enables or disables Intel® Virtualization Technology for Directed I/O (VT-d) by reporting the I/O device assignment to VMM through DMAR ACPI tables.

## PCH Configuration



## PCH Devices



### SMBUS Device

Enables or disables SMBUS device.

### PCH Display

Enables or disables the PCH Display.

### External SSC Enable


Enables or disables External SSC.

### PCH State After G3

Configures the PCH state after G3.




## PCI Express Configuration



### PCI Express Root Port 2, 3, 4 and 5

Settings for PCI Express Root Port 2, 3, 4 and 5.

## PCI Express Root Port 2



### PCI Express Root Port

Enables or disables the PCIe root port.

## PCI Express Root Port 3 to Port 5




### PCI Express Root Port

Enables or disables the PCIe root port.

### PCIe Speed

Configures the PCIe speed for the root port.

## PCH sSATA Configuration



### SATA Controller

Enables or disables the SATA controller.

### Configure SATA as

Configures the SATA as IDE or AHCI.

**IDE** This option configures the Serial ATA drives as Parallel ATA physical storage device.

**AHCI** This option configures the Serial ATA drives to use AHCI (Advanced Host Controller Interface). AHCI allows the storage driver to enable the advanced Serial ATA features which will increase storage performance.

### Port 0 to Port 2

Enables or disables sSATA port 0 to port 2.

### Hot Plug

Enables or disables hot plugging feature on sSATA port 0, port 1 and port 2.

### sSATA Device Type

Identifies what type of sSATA device is connected.

## PCH SATA Configuration



### SATA Controller


Enables or disables the SATA controller.

### Configure SATA as

Configures the SATA as IDE or AHCI.

**IDE** This option configures the Serial ATA drives as Parallel ATA physical storage device.

**AHCI** This option configures the Serial ATA drives to use AHCI (Advanced Host Controller Interface). AHCI allows the storage driver to enable the advanced Serial ATA features which will increase storage performance.



### Port 0 to Port 5

Enables or disables SATA port 0 to port 5.

### Hot Plug

Enables or disables hot plugging feature on SATA port 1, port 2, port 3, port 4 and port 5.

### SATA Device Type

Identifies what type of SATA device is connected.

## USB Configuration



### xHCI Mode

Configures the XHCI mode.

### Trunk Clock Gating

Enables or disables Trunk Clock Gating.

## Network Configuration




### ByPass Auto Detect

Enables or disables automatic LAN Bypass function.

## Security

This section is used to configure the processor and chipset settings.



### Administrator Password

Select this to reconfigure the administrator's password.

## Boot

This section is used to configure the boot features.



### Setup Prompt Timeout

Selects the number of seconds to wait for the setup activation key. 65535(0xFFFF) denotes indefinite waiting.

### Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

### Quiet Boot

Enabled            Displays OEM logo instead of the POST messages.  
Disabled          Displays normal POST messages.

### Boot mode select

Configures the boot mode option.


### Fixed Boot Order Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.

### USB Key Drive BBS Priorities

Adjust the boot sequence for USB devices. Boot Option #1 is the first boot device that the system will boot from, next will be Boot Option #2 and so forth.

## Save & Exit



### Save Changes and Exit

To save the changes and exit the Setup utility, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes. You can also press <F4> to save and exit Setup.

### Discard Changes and Exit

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting. You can also press <ESC> to exit without saving the changes.

### Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Discard Changes and Reset

To exit the Setup utility and reset without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

### Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Boot Override

To bypass the boot sequence from the Boot Option List and boot from a particular device, select the desired device and press <Enter>.