



NEXCOM International Co., Ltd.

Network and Communication Solutions

Network Security Appliance

NSA 7146

User Manual

NEXCOM International Co., Ltd.

Published June 2020

www.nexcom.com

CONTENTS

Preface

Copyright	iv
Disclaimer	iv
Acknowledgements	iv
Regulatory Compliance Statements	iv
Declaration of Conformity	iv
RoHS Compliance	v
Warranty and RMA	vi
Safety Information	viii
Installation Recommendations	viii
Safety Precautions	ix
Technical Support and Assistance	x
Conventions Used in this Manual	x
Global Service Contact Information	xi
Package Contents	xiii
Ordering Information	xiv

Chapter 1: Product Introduction

Overview	1
Key Features	1
Hardware Specifications	2
Knowing Your NSA 7146	3
Front Panel	3
Rear Panel	4

Chapter 2: Jumpers and Connectors

Before You Begin	5
Precautions	5
Jumper Settings	6
Locations of the Jumpers and Connectors	7
Jumper	8
RTC Clear	8
Internal Connectors	9
Power Button Header	9
System Fan Connectors	9
BMC Debug Header	10
USB 2.0 Connectors	10
Internal Power Connector	11
ATX 12V Internal Power Connector	11
Internal Power Connector	12
Battery Connector	12
Connector	13
VGA Connector	13
Digital Power Debug Pin Header	14
CPU TAP1 Pin Header	14
PCH TAP2 Header	15
FPGA CPU1 GPIO Connectors	15
TPM Header	16
Block Diagram	17



Chapter 3: System Setup

Removing the Chassis Cover 18

Installing a LAN Module 19

Installation Sequence of CPU and Memory 21

Assembling the 2.5" Removable Drive Bay 22

Assembling the 3.5" Removable Drive Bay 27

Chapter 4: BIOS Setup

About BIOS Setup 33

When to Configure the BIOS 33

Default Configuration 34

Entering Setup 34

Legends 34

BIOS Setup Utility 36

 Main 36

 Advanced 37

 Platform Configuration 46

 Socket Configuration 51

 Server Mgmt 74

 Security 80

 Boot 80

 Save & Exit 81



PREFACE

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from NEXCOM International Co., Ltd.

Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from NEXCOM International Co., Ltd. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.nexcom.com>. NEXCOM shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

Acknowledgements

NSA 7146 is a trademark of NEXCOM International Co., Ltd. All other product names mentioned herein are registered trademarks of their respective owners.

Regulatory Compliance Statements

This section provides the FCC compliance statement for Class A devices and describes how to keep the system CE compliant.

Declaration of Conformity

FCC

This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

RoHS Compliance



NEXCOM RoHS Environmental Policy and Status Update

NEXCOM is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, NEXCOM has established an engineering and manufacturing task force in to implement the introduction of green products. The task force will ensure that we follow the standard NEXCOM development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which NEXCOM are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

How to recognize NEXCOM RoHS Products?

For existing products where there are non-RoHS and RoHS versions, the suffix "(LF)" will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual NEXCOM naming convention.

Warranty and RMA

NEXCOM Warranty Period

NEXCOM manufactures products that are new or equivalent to new in accordance with industry standard. NEXCOM warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by NEXCOM.

NEXCOM Return Merchandise Authorization (RMA)

- Customers shall enclose the “NEXCOM RMA Service Form” with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the “NEXCOM RMA Service Form” for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, NEXCOM is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as “Out of Warranty.”
- Any products returned by NEXCOM to other locations besides the customers’ site will bear an extra charge and will be billed to the customer.

Repair Service Charges for Out-of-Warranty Products

NEXCOM will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

System Level

- Component fee: NEXCOM will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with NEXCOM products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

Board Level

- Component fee: NEXCOM will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.

Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

Technical Support and Assistance

1. For the most updated information of NEXCOM products, visit NEXCOM's website at www.nexcom.com.
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
 - Product name and serial number
 - Detailed information of the peripheral devices
 - Detailed information of the installed software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wordings of the error messages

Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

Conventions Used in this Manual



Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



Caution:

Information to avoid damaging components or losing data.



Note:

Provides additional information to complete a task easily.

Global Service Contact Information

Headquarters

NEXCOM International Co., Ltd.

9F, No. 920, Chung-Cheng Rd.,
ZhongHe District, New Taipei City, 23586,
Taiwan, R.O.C.

Tel: +886-2-8226-7786

Fax: +886-2-8226-7782

www.nexcom.com

Asia

Taiwan

NexAIoT Co., Ltd.

Taipei Office

13F, No.920, Chung-Cheng Rd.,
ZhongHe District,
New Taipei City, 23586, Taiwan, R.O.C.

Tel: +886-2-8226-7796

Fax: +886-2-8226-7792

Email: sales@nexcom.com.tw

www.nexcom.com.tw

NexAIoT Co., Ltd.

Taichung Office

16F, No.250, Sec. 2, Chongde Rd.,
Beitun Dist.,

Taichung City 406, R.O.C.

Tel: +886-4-2249-1179

Fax: +886-4-2249-1172

Email: sales@nexcom.com.tw

www.nexcom.com.tw

NexCOBOT Taiwan Co., Ltd.

13F, No.916, Chung-Cheng Rd.,
ZhongHe District,
New Taipei City, 23586, Taiwan, R.O.C.

Tel: +886-2-8226-7796

Fax: +886-2-8226-7792

Email: sales@nexcom.com.tw

www.nexcom.com.tw

GreenBase Technology Corp.

13F, No.922, Chung-Cheng Rd.,
Zhonghe Dist.,
New Taipei City, 23586, Taiwan, R.O.C.

Tel: +886-2-8226-7786

Fax: +886-2-8226-7900

Email: sales@nexcom.com.tw

www.nexcom.com.tw

China

NEXSEC Incorporated

Floor 5, No.4, No.7 fengxian middle Rd.,
(Beike Industrial Park), Haidian District,
Beijing, 100094, China

Tel: +86-10-5704-2680

Fax: +86-10-5704-2681

Email: sales@nexcom.cn

www.nexcom.cn

NEXCOM Shanghai

Room 603/604, Huiyinmingzun Plaza Bldg., 1,
No. 609, Yunlin East Rd.,
Shanghai, 200062, China
Tel: +86-21-5278-5868
Fax: +86-21-3251-6358
Email: sales@nexcom.cn
www.nexcom.cn

NEXCOM Surveillance Technology Corp.

Floor 5, Building C, ZhenHan Industrial Zone,
GanKeng Community, Buji Street,
LongGang District,
ShenZhen, 518112, China
Tel: +86-755-8364-7768
Fax: +86-755-8364-7738
Email: steveyang@nexcom.com.tw
www.nexcom.cn

NEXCOM United System Service

Room 603/604, Huiyinmingzun Plaza Bldg. 1,
No. 609, Yunlin East Rd.,
Shanghai, 200062, China
Tel: +86-21-5278-5868
Fax: +86-21-3251-6358
Email: renwang@nexcom.com.tw
www.nexcom.cn

NEXGOL

1st Floor, Building B4, Electronic 2nd Area,
(Phoenix Lake Industrial Park), Yongchuan Dist.,
Chongqing City, 402160, China
Tel: +86-23-4960-9080
Fax: +86-23-4966-5855
Email: sales@nexcobot.com
www.nexgol.com/NexGoL

Beijing NexGemo Technology Co.,Ltd.

5th Floor, Gemotech Building, No.1, Development Rd.,
Changping International Information Industry Base,
Changping District,
Beijing, 102206, China
Tel: +86-10-8190-9399
Fax: +86-10-8190-9456

Japan**NEXCOM Japan**

9F, Tamachi Hara Bldg.,
4-11-5, Shiba Minato-ku,
Tokyo, 108-0014, Japan
Tel: +81-3-5419-7830
Fax: +81-3-5419-7832
Email: sales@nexcom-jp.com
www.nexcom-jp.com

Europe**United Kingdom****NEXCOM EUROPE**

10 Vincent Avenue,
Crownhill Business Centre,
Milton Keynes, Buckinghamshire
MK8 0AB, United Kingdom
Tel: +44-1908-267121
Fax: +44-1908-262042
Email: sales.uk@nexcom.eu
www.nexcom.eu

America**USA****NEXCOM USA**

2883 Bayview Drive,
Fremont CA 94538, USA
Tel: +1-510-656-2248
Fax: +1-510-656-2158
Email: sales@nexcom.com
www.nexcom.com

Package Contents

Before continuing, verify that the NSA 7146 package that you received is complete. Your package should have all the items listed in the following table.

Item	Part Number	Name	Qty
1	19S00714600X0	NSA 7146	1
2	6023309081X00	DB9-to-RJ45 Console Cable	1
3	50311F0100X00	Round Head Screw with Spring	1
4	50311F0110X00	Flat Head Screw	8
5	50311F0162X00	Round Head Screw with Washer	1
6	5044440031X00	Rubber Foot Set	4
7	5040150001X00	Hook Handle (For retrieving LAN module)	1
8	50311F0512X00	F Head Screw	8
9	5061700467X00	LGA3647 CPU Carrier	2

Ordering Information

The following information below provides ordering information for NSA 7146.

Barebone

NSA 7146 (P/N: TBC)

2U Intel® Xeon® PCH C621, with LCM, 2 swappable 2.5" HDD trays,
3 swappable system fans, 8 LAN module (NI/NX series) bays, 700W PSU

LAN Modules

Model	P/N	Interface	Type	Port Number	Bypass/Segment	Expansion Slot	Location Slot
NX 140F	10S20140F01X0	XL710-BM1	PCIe x8	4 SFP+	None	None	All Slot
NX 142F	10S20142F01X0	XL710-BM1	PCIe x8	4 SFP+	2 bypass	None	All Slot
NX 142F-LR	10S20142F03X0	XL710-BM1	PCIe x8	4 SFP+	2 bypass	None	All Slot
NX 120F	10S20120F00X0	X710-BM2	PCIe x8	2 SFP+	None	None	All Slot
NI 140F	10SK000NI02X0	i350AM4x1	PCIe x8	4 SFP	None	None	All Slot
NI 180F	10S10180F01X0	i350AM4x2	PCIe x8	8 SFP	None	None	All Slot
NI 142C	10SK000NI03X0	i350AM4x1	PCIe x8	4 Copper	2 bypass	None	All Slot
NI 180C	10S10180C01X0	i350AM4x2	PCIe x8	8 Copper	None	None	All Slot
NI 184C	10S10184C01X0	i350AM4x2	PCIe x8	8 Copper	4 bypass	None	All Slot
NI 142F	10S10142F01X0	i350AM4x1	PCIe x8	4 SFP	2 bypass	None	All Slot
NI 121F	10S10121F01X0	i350AM2x1	PCIe x8	2 SFP	1 bypass	None	All Slot
NI 140C	10S10140C01X0	i350AM4x1	PCIe x8	4 Copper	None	None	All Slot
NV 120F	10S50120F01X0	XXV710-AM2	PCIe x8	2 SPF28	None	None	All Slot
NC220Q28M	10S30022002X0	MT27708A0-FDCF-CE	PCIe x16	2 QSFP28	None	None	1,2/ 3,4/ 5,6/ 7,8

CHAPTER 1: PRODUCT INTRODUCTION

Overview



Key Features

- Dual Intel® Xeon® scalable processor family
- Support processor-FPGA solution
- Support up to 512GB of DDR4 2133/2400/2666 ECC & REG memory
- Up to 8 slots for PCIe LAN modules
- 2 x 2.5" SATA/SAS HDDs (swappable)
- CRPS (1 + 1) redundant power supply
- Support BMC with IPMI 2.0 and out-of-band management
- Optional TPM 1.2/2.0 module
- Support IPMI 2.0
- Support Intel® QAS® ready

Hardware Specifications

Main Board

- NSB 7145
- Dual Intel® Xeon® processor scalable family
- Support 10.4 GT/s UPI
- Intel® C627

Main Memory

- 16 x 284-pin DDR4 2133/2400/2666 DIMM sockets, up to 512GB ECC & REG SDRAM

LAN Features

- Swappable LAN modules
- Support Intel® i350/Intel® XL710 copper/fiber ports
- Support 10/100/1000/10G/100G link speed
- LAN Bypass:

* Please see LAN module list information

I/O Interface-Front

- Support 2 x 20 characters LCD module, SIO interface
- Power status/HDD status/GPIO status/system failure status LEDs
- 2 x 2.5" HDD swappable bays
- 8 x LAN module bays
- 2 x USB 3.0 ports
- 1 x micro USB type console port
- 1 x RJ45 type console port
- 2 x Management LAN ports

I/O Interface-Rear

- 3 x Swappable system fans
- 1 x Power button switch
- 1 x VGA Port
- 2 x USB 2.0 ports

Storage

- 1 x On-board CFast socket

Power Input

- 700W 1+1 CRPS redundant power supply

Chassis Dimensions

- Chassis dimension: 438 mm x 570 mm x 88 mm
- Carton dimension: 774 mm x 636 mm x 293 mm

Weight

- Without packing: 19kg
- With packing: 25kg

Environment


- Operating temperature: 0°C~40°C
- Storage temperature: -20°C~75°C
- Relative humidity: 10%~90% non-condensing

Certifications

- CE approval
- FCC Class A
- UL

Knowing Your NSA 7146

Front Panel



LCD

2x20 characters LCD module, SIO interface.

HDD Bays

Two 2.5" HDD swappable bays for installing HDDs.

LED Indicators

Indicates the power status, system failure status, hard drive and GPIO activity of the system.

RJ45/Micro USB Type Console Serial Port

Used to connect console devices with RJ45/Micro USB type connection.

USB Ports

Used to connect USB 3.0/2.0/1.1 devices.

Management LAN Ports

Two LAN ports used for managing the system.


Reset Button

Press to restart the system.

LAN Modules

Eight LAN module bays.

Rear Panel



Power Switch

Press to power-on or power-off the system.

VGA

Used to connect an analog VGA monitor.

USB Ports

Used to connect USB 2.0/1.1 devices.

AC Power Sockets

Dual redundant power supply sockets, plug an AC power cord here before turning on the system.

CHAPTER 2: JUMPERS AND CONNECTORS

This chapter describes how to set the jumpers and connectors on the NSA 7146 motherboard.

Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
 - A Philips screwdriver
 - A flat-tipped screwdriver
 - A set of jewelers screwdrivers
 - A grounding strap
 - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short



Locations of the Jumpers and Connectors

The figure below shows the location of the jumpers and connectors.





Jumper

RTC Clear

Connector type: 1x3 3-pin header
Connector location: JP8



Pin	Function
1-2 On	Normal
2-3 On	Clear CMOS

1-2 On: default

Pin	Definition
1	NC
2	RST_RTCRST_N
3	GND



Internal Connectors

Power Button Header

Connector type: 1x2 2-pin header
Connector location: JPWRBTN1



Pin	Definition
1	FP_PWRBTN_R_N
2	GND

System Fan Connectors

Connector type: 2x2 4-pin header
Connector location: CN3, CN4 and CN5



Pin	Definition	Pin	Definition
1	GND	2	SYS_FAN3_TACH_P
3	SYS_FAN3_PWM	4	P12V





BMC Debug Header


Connector type: 1x2 2-pin header
Connector location: JP10



Pin	Definition
1	BMC_COM_SW_N
2	GND

USB 2.0 Connectors

Connector type: 1x6 6-pin header
Connector location: CN7




Pin	Definition	Pin	Definition
1	P5V_USB_P34	2	USB2N3_C
3	USB2P3_C	4	USB2N4_C
5	USB2P4_C	6	GND



Internal Power Connector


Connector type: 2x8 16-pin header
Connector location: CON1



Pin	Definition	Pin	Definition
1	P12V	2	P12V
3	P12V	4	P12V
5	P12V	6	P12V
7	P12V	8	P12V
9	GND	10	GND
11	GND	12	GND
13	GND	14	GND
15	GND	16	GND

ATX 12V Internal Power Connector


Connector type: 2x2 4-pin header
Connector location: CON2



Pin	Definition	Pin	Definition
1	GND	2	GND
3	P12V_V1	4	P12V_V1

Internal Power Connector


Connector type: 2x12 24-pin header
Connector location: CON3



Pin	Definition	Pin	Definition
1	+3.3V	2	+3.3V
3	GND	4	+5V
5	GND	6	+5V
7	GND	8	PW-OK
9	+5VSB	10	+12V
11	+12V	12	+3.3V
13	+3.3V	14	-12V
15	GND	16	PS-ON
17	GND	18	GND
19	GND	20	RES/-5V
21	+5V	22	+5V
23	+5V	24	GND

Battery Connector

Connector type: 1x2 2-pin header
Connector location: J1



Pin	Definition
1	GND
2	RTC_BAT



Connector


Connector type: 1x2 2-pin header
Connector location: J2



Pin	Definition
1	P5V
2	GND

VGA Connector

Connector type: 1x16 16-pin header
Connector location: J3



Pin	Definition	Pin	Definition
1	VGA_VCC	2	GND
3	N/C	4	DDC_CLKO_B
5	DDC_DATAO_B	6	N/C
7	AVSYNCO_B	8	GND
9	AHSYNCO_B	10	VGA_VCC
11	GND	12	DACBOA_B
13	GND	14	DACGOA_B
15	GND	16	DACROA_B





Digital Power Debug Pin Header

Connector type: 1x3 3-pin header
Connector location: JP1 and JP2



Pin	Definition
1	SMB_PMBUS2_STBY_LVC3_SCL
2	SMB_PMBUS2_STBY_LVC3_SDA
3	GND

CPU TAP1 Pin Header

Connector type: 1x5 5-pin header
Connector location: JP4



Pin	Definition
1	JTAG_XDP_CPU_QS_GTL_TRST_N
2	JTAG_CPU1_MUX_GTL_TDO_R
3	JTAG_MUX_CPU0_GTL_TDI
4	JTAG_XDP_CPU_QS_GTL_TMS
5	JTAG_XDP_CPU_GTL_TCK



PCH TAP2 Header


Connector type: 1x5 5-pin header
Connector location: JP5



Pin	Definition
1	N/C
2	JTAG_QS_XDP_GTL_TDO
3	JTAG_XDP_QS_GTL_TDI
4	JTAG_XDP_CPU_GTL_TMS
5	JTAG_XDP_PCH_TCK1

FPGA CPU1 GPIO Connectors

Connector type: 2x7 14-pin header
Connector location: JP6 and JP7




Pin	Definition	Pin	Definition
1	N/C	2	P3V3
3	PWRGD_PVCCH_CPU1_DLY	4	SMB_CPU1_RC_I2C1_RESET_N
5	FM_CPU1_RC_GPIO_B_4	6	GND
7	FM_CPU1_RC_GPIO_B_3	8	GND
9	FM_CPU1_RC_GPIO_B_2	10	GND
11	FM_CPU1_RC_GPIO_B_1	12	GND
13	FM_CPU1_RC_GPIO_B_0	14	GND



TPM Header


Connector type: 2x7 14-pin header
Connector location: JP15



Pin	Definition	Pin	Definition
1	GND	2	CLK_24M_66M_LPC0_ESPI_TPM
3	NC	4	LPC_LFRAME_N_ESPI_CS0_N_TPM
5	LPC_LAD2_ESPI_IO2_TPM	6	RST_R1_N_TPM
7	LPC_LAD1_ESPI_IO1_TPM	8	LPC_LAD3_ESPI_IO3_TPM
9	GND	10	LPC_LAD0_ESPI_IO0_TPM
11	IRQ_LPC_SERIRQ_ESPI_CS1_N_TPM	12	P3V3
13	GND	14	GND



Block Diagram




CHAPTER 3: SYSTEM SETUP

Removing the Chassis Cover




Prior to removing the chassis cover, make sure the unit's power is off and disconnected from the power sources to prevent electric shock or system damage.

1. The screws on the bottom and sides are used to secure the cover to the chassis. Remove these screws and put them in a safe place for later use.




Screws on the sides



Screws on the top

2. With the screws removed, gently slide the cover outwards and then lift up the cover to remove it.




Installing a LAN Module




Please correctly follow the below instructions and noted items to avoid making unnecessary damages. Make sure the power supply is switched off and disconnected from the power sources before replacing or adding LAN modules to prevent electric shock or system damage.

1. Remove the screw on the LAN module then put them in a safe place for later use.




2. Use the handle provided, and insert the handle into the two holes on the LAN module.



3. Once the handle is firmly secured in position, pull the handle outwards to remove the LAN module.



4. Insert the new LAN module into the slot and secure the module with screws.


**Important:**

Before using Optical fiber for transferring data, make sure you have connected an approved Optical Transceiver Module. User needs to install appropriate and UL approved Laser Class I Transceivers, rated 3.3Vdc, max. 1W.

Installation Sequence of CPU and Memory

CPU Installation

When installing a CPU into the system, please install it into socket CPU 0 first as depicted below.




Socket CPU 0

Socket CPU 1

Memory Installation


When installing memory modules into the system, please install the first and second memory module into the memory slots in the numerical sequence as depicted below.




Note: The system may not boot if the first memory module is not installed in slot 1 labeled above.

Assembling the 2.5" Removable Drive Bay


The 2.5" removable drive bay kit contains the parts pictured below:




1. Locate the installation location for the drive bay kit.




2. Install the two copper standoffs to the location circled below.




3. Align the mounting holes on the base plate to the copper standoffs.



4. Secure the base plate to the standoffs with screws.



5. Align the mounting holes on the drive bay enclosure to the mounting holes on the drive bay bracket.





6. Secure the drive bay enclosure to the bracket with screws.




7. Repeat step 6 for securing the screws on the other side of the bracket.

8. Fix the drive bay bracket to the base plate with screws.




9. Connect the SATA data and power cables to the respective connectors on the board and the other ends of the cables to the connectors on the drive bay enclosure.




Assembling the 3.5" Removable Drive Bay


The 3.5" removable drive bay kit contains the parts pictured below:




1. Locate the installation location for the drive bay kit.




2. Install the two copper standoffs to the location circled below.



3. Align the mounting holes on the base plate to the copper standoffs.



4. Secure the base plate to the standoffs with screws.




5. Push the eject button on the HDD drive tray to release the latch.



Eject button

6. Grab on the latch and pull the drive tray out gently.



Latch

7. Place the SATA drive onto the tray and align the mounting holes on the drive with the mounting holes on the tray, then secure the drive in place with screws.




8. Repeat step 7 for securing the screws on the other side of the HDD tray.


9. Slide the tray back into the drive bay enclosure, and push firmly until you hear a distinctive click sound.



10. Fix the drive bay enclosure to the base plate with screws.



11. Connect the SATA data and power cables to the respective connectors on the board and the other ends of the cables to the connectors on the drive bay enclosure.



CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for NSA 7146. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the NEXCOM website at www.nexcom.com.tw.

About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.



Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.












Entering Setup

When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing  allows you to enter Setup.

Legends


Key	Function
	Moves the highlight left or right to select a menu.
	Moves the highlight up or down between sub-menu or fields.
	Exits the BIOS Setup Utility.
	Scrolls forward through the values or options of the highlighted field.
	Scrolls backward through the values or options of the highlighted field.
	Selects a field.
	Displays General Help.
	Load previous values.
	Load optimized default values.
	Saves and exits the Setup program.
	Press <Enter> to enter the highlighted sub-menu



Scroll Bar


When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

Submenu

When “▶” appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .



BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1998 to 9999.

System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.



Setting incorrect field values may cause the system to malfunction.



Trusted Computing

This section is used to configure Trusted Platform Module (TPM) settings.



Security Device Support

Enables or disables BIOS support for security device. O.S will not show Security Device. TCG EFI protocol and INT1A interface will not be available.



AST2400 Super IO Configuration

This section is used to configure the serial port.



Super IO Chip

Displays the Super I/O chip used on the board.

Serial Port 1 Configuration

Configuration settings for serial port 1.

Serial Port 2 Configuration

Configuration settings for serial port 2.

Serial Port 1 Configuration

This section is used to configure serial port 1.



Serial Port

Enables or disables the serial port.

Change Settings

Selects an optimal setting for the Super IO device.





Serial Port 2 Configuration

This section is used to configure serial port 2.

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Advanced

Serial Port 2 Configuration

Serial Port [Enabled]

Device Settings IO=2F8h; IRQ=3;

Change Settings [Auto]

Enable or Disable Serial Port (COM)

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275, Copyright (C) 2019 American Megatrends, Inc.

Serial Port


Enables or disables the serial port.

Change Settings

Selects an optimal setting for the Super IO device.


Hardware Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



P12V_SCALED to SMB_TMP0

Detects and displays the output voltages, temperatures and fan speeds.



PVDDQ_ABC to PSU1_FAN

Detects and displays the output voltages, temperatures and fan speeds.

Serial Port Console Redirection

This section is used to configure the serial port that will be used for console redirection.




Console Redirection

Enables or disables console redirection for COM0.

Console Redirection Settings (COM0)

Specifies how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.



Terminal Type

- ANSI Extended ASCII character set.
- VT100 ASCII character set.
- VT100+ Extends VT100 to support color, function keys, etc.
- VT-UTF8 Uses UTF8 encoding to map Unicode characters onto 1 or more bytes.

Bits Per Second

Selects the serial port transmission speed. The speed must match the other side. Long or noisy lines may require a lower speed.

Data Bits

The options are 7 and 8.

Parity

A parity bit can be sent with the data bits to detect some transmission errors.

Even Parity bit is 0 if the number of 1's in the data bits is even.

Odd Parity bit is 0 if number of 1's in the data bits is odd.

Stop Bits

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

Flow Control

Flow control can prevent data loss from buffer overflow. When sending data and the receiving buffers are full, a "stop" signal can be sent to stop the data flow.

VT-UTF8 Combo Key Support

Enables or disables VT-UTF8 combo key support.

Recorder Mode

When this field is enabled, only text will be sent. This is to capture the terminal data.

Resolution 100x31

Enables or disables extended terminal resolution.

Putty KeyPad

Selects the Putty keyboard emulation type.

PCI Subsystem Settings

This section is used to configure the PCI.



Above 4G Decoding

Enables or disables decoding of 64-bit devices in 4G address space. (Only if the system supports 64-bit PCI decoding.)

SR-IOV Support

Enables or disables SR-IOV support.

BME DMA Mitigation

Enables or disables the function to re-enable bus master attribute during PCI enumeration for PCI bridges after SMM is locked.

USB Configuration

This section is used to configure the USB.




Legacy USB Support

- Enable Enables Legacy USB.
- Auto Disables support for Legacy when no USB devices are connected.
- Disable Keeps USB devices available only for EFI applications.

XHCI Hand-off

This is a workaround for OSs that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver.



USB Mass Storage Driver Support

Enables or disables USB mass storage device driver support.

Port 60/64 Emulation

Enables I/O port 60h/64h emulation support. This should be enabled for complete USB keyboard legacy support for non-USB aware OS.

USB transfer time-out

The time-out value for control, bulk, and Interrupt transfers.



Device reset time-out

Selects the USB mass storage device’s start unit command timeout.

Device power-up delay

Maximum time the value will take before it properly reports itself to the Host Controller. “Auto” uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

Mass Storage Devices:

Selects the mass storage device emulation type.

CSM Configuration

This section is used to configure the compatibility support module features.



CSM Support

This field is used to enable or disable CSM support, if Auto option is selected, based on OS, CSM will be enabled or disabled automatically.

GateA20 Active

Upon Request GA20 can be disabled using BIOS services.
Always Do not allow disabling of GA20; this option is useful when any RT code is executed above 1MB.



Option ROM Messages

This field is used to set display mode for Option ROM. The options are Force BIOS and Keep Current.

INT19 Trap Response

Allows Option ROMs to trap Interrupt 19 when enabled.

- Immediate Execute the trap right away.
- Postponed Execute the trap during legacy boot.

HDD Connection Order

Configures the HDD handles to be adjusted.

Network

Controls the execution of UEFI and Legacy PXE OpROM.

Storage

Controls the execution of UEFI and Legacy Storage OpROM.

Video

Controls the execution of UEFI and Legacy Video OpROM.

Other PCI Devices

Configures the OpROM execution policy for devices other than Network, Storage or Video.

Network Stack Configuration

This section is used to configure the network stack.



Network Stack

Enables or disables UEFI network stack.



Platform Configuration



PCH Configuration

Enters the PCH Configuration submenu.

Network Configuration

Enters the Network Configuration submenu.

Server ME Debug Configuration

Enters the Server ME Debug Configuration submenu.

PCH Configuration



PCH Devices

Enters the PCH Devices submenu.

PCI Express Configuration

Enters the PCI Express Configuration submenu.

PCH SATA Configuration

Enters the PCH SATA Configuration submenu.

USB Configuration

Enters the USB Configuration submenu.





PCH Devices

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Platform Configuration

External SSC Enable - Pcie Pll SSC	[Disable] [Disable]	Enable Spread Spectrum - only affects external clock generator
		→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

External SSC Enable

Enables or disables spread spectrum clock. Only affects external clock generator.

Pcie Pll SSC

Enables or disables PCIe Phase Locked Loop for spread spectrum clock.

PCI Express Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Platform Configuration


Max Read Request Size	[MRRS 1024B]	PCIe Max Read Request Size Selection.
		→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Max Read Request Size

Configures the PCIe max read request size.

PCH SATA Configuration




SATA Controller(s)

Enables or disables the SATA controller.

Configure SATA as

Configures the SATA mode.

AHCI This option configures the Serial ATA drives to use AHCI (Advanced Host Controller Interface). AHCI allows the storage driver to enable the advanced Serial ATA features which will increase storage performance.



Port 0 to Port 6

Enables or disables SATA port 0 to port 6.

Hot Plug

Enables or disables hot plugging feature on SATA port 0 to port 6.



USB Configuration (PCH)

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Platform Configuration

XHCI Manual Mode USB Per-Connector Disa	[Disable] [Disable]	Use by validation, not for end-user.
		→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

XHCI Manual Mode

Enables or disables XHCI manual mode.

USB Per-Connector Disable

Provides the option to enable or disable each USB connector.

Network Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Platform Configuration

Network Configuration	Switch ByPass Auto Detect to Enable/Disable
ByPass Auto Detect [Enable]	
If all the PCIE slots don't insert the Lan Module or all the Lan Modules don't support ByPass function, the options of the ByPass will not be shown!!	
→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

ByPass Auto Detect

Enables or disables automatic LAN Bypass function.




Server ME Debug Configuration



Server ME General Configuration

Enters the Server ME General Configuration submenu.

Server ME General Configuration




Override ICC Clock Settings

Enters the Override ICC Clock Settings submenu.



Override ICC Clock Settings



Override ICC Clock Settings

Provides the option to allow customization of clock settings.

ICC Clock Spread Spectrum

Enables or disables ICC Clock Spread Spectrum.

Socket Configuration



Processor Configuration

Enters the Processor Configuration submenu.

Common RefCode Configuration

Enters the Common RefCode Configuration submenu.

UPI Configuration and Memory Configuration

Enters the UPI Configuration and Memory Configuration submenu.

IIO Configuration and Advanced Power Management Configuration

Enters the IIO Configuration and Advanced Power Management Configuration submenu.



Processor Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Processor Configuration

Per-Socket Configuration

Processor BSP Revision

50656 - CLX B0

Processor Socket

Socket 0

Socket 1

Processor ID

00050656*

00050656

Processor Frequency

2.400GHz

2.400GHz

Processor Max Ratio

18H

18H

Processor Min Ratio

0AH

0AH

Microcode Revision

0400001C

0400001C

L1 Cache RAM

64KB

64KB

L2 Cache RAM

1024KB

1024KB

L3 Cache RAM

36608KB

36608KB

Processor 0 Version

Intel (R) Xeon (R) Platinum 8260C CPU @ 2.40GHz

Processor 1 Version

Intel (R) Xeon (R) Platinum 8260C CPU @ 2.40GHz

Change Per-Socket Settings

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Hyper-Threading [ALL]

Enables or disables hyper-threading technology.

Hardware Prefetcher

Enables or disables the MLC streamer prefetcher.

L2 RFO Prefetch Disable

Enables or disables L2 RFO prefetch.

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Processor ID

00050656*

00050656

Processor Frequency

2.400GHz

2.400GHz

Processor Max Ratio

18H

18H

Processor Min Ratio

0AH

0AH

Microcode Revision

0400001C

0400001C

L1 Cache RAM

64KB

64KB

L2 Cache RAM

1024KB

1024KB

L3 Cache RAM

36608KB

36608KB

Processor 0 Version

Intel (R) Xeon (R) Platinum 8260C CPU @ 2.40GHz

Processor 1 Version

Intel (R) Xeon (R) Platinum 8260C CPU @ 2.40GHz

Hyper-Threading [ALL]

[Disable]

Hardware Prefetcher

[Disable]

L2 RFO Prefetch Disable

[Disable]

Adjacent Cache Prefetcher

[Enable]

Extended APIC

[Disable]

Enable/disable extended APIC support

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Adjacent Cache Prefetcher

Enables or disables prefetching of adjacent cache lines.

Extended APIC

Enables or disables extended APIC support.



Per-Socket Configuration




CPU Socket 0 Configuration

Processor settings for the CPU on socket 0.

CPU Socket 1 Configuration

Processor settings for the CPU on socket 1.

CPU Socket 0 Configuration



Cores Disable Bitmap

Provides the option to enable or disable all cores. 0 means enable all cores. FFFFFFFF means disable all cores.

IOT Cfg

Enables or disables IOT Cfg.



CPU Socket 1 Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU Socket 1 Configuration

Fused Core Bitmap: 0x01FFFFFB

Available Bitmap: 0x01FFFFFB

Core Disable Bitmap(He0

IOT Cfg[Disable]

0: Enable all cores.
FFFFFFF: Disable all cores
NOTE: At least one core per
CPU must be enabled.
Disabling all cores is an invalid
configuration.

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Cores Disable Bitmap

Provides the option to enable or disable all cores. 0 means enable all cores. FFFFFFFF means disable all cores.

IOT Cfg

Enables or disables IOT Cfg.

Common RefCode Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Common RefCode Configuration

Isoc Mode[Disable]

Numa[Enable]

Isoc: Disable,Enable

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Isoc Mode

Enables or disables Isochronous support.

Numa

Enables or disables Non-Uniform Memory Access support.

UPI Configuration




UPI General Configuration

Enters the UPI General Configuration submenu.

UPI Per Socket Configuration

Enters the UPI Per Socket Configuration submenu.

UPI General Configuration



Link Speed Mode

Configures the link speed mode.

Link Frequency Select

Configures the UPI frequency.



UPI Status

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

UPI Status

-----...

Number of CPU2

Number of IIO2

Current UPI Link SpeedFast

Current UPI Link Frequ10.4 GT/s

UPI Global MMIO Low Ba90000000 / FBFFFFFFF

UPI Global MMIO High B0000000000000000 / 0. . .

UPI Pci-e Configuratio80000000 / 10000000

-----> Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Displays information on the current UPI configuration.

UPI Per Socket Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

UPI Per Socket Configuration

-----...

▶ CPU 0

▶ CPU 1

CPU 0 Configuration Silk Screen Equivalent->CPU 1

-----> Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.


CPU 0
Enters the CPU 0 submenu.

CPU 1
Enters the CPU 1 submenu.





UPI Per Socket Configuration CPU 0



CPU 0 UPI Port 0

Enters the CPU 0 UPI Port 0 configuration submenu.


CPU 0 UPI Port 1

Enters the CPU 0 UPI Port 1 configuration submenu.

CPU 0 UPI Port 2

Enters the CPU 0 UPI Port 2 configuration submenu.

UPI Per Socket Configuration CPU 1



CPU 1 UPI Port 0

Enters the CPU 1 UPI Port 0 configuration submenu.

CPU 1 UPI Port 1

Enters the CPU 1 UPI Port 1 configuration submenu.

CPU 1 UPI Port 2

Enters the CPU 1 UPI Port 2 configuration submenu.



CPU 0 UPI Port 0

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU 0 UPI Port 0

Link Disable [No]
UPI VNA Credit Overrid 7f
Current UPI Link Speed [Auto]

UPI Link Disable

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Disable

Enables or disables the UPI link.

Current UPI Link Speed

Configures the current UPI link speed.

CPU 0 UPI Port 1

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU 0 UPI Port 1

Link Disable [No]
UPI VNA Credit Overrid 7f
Current UPI Link Speed [Auto]

UPI Link Disable

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Disable

Enables or disables the UPI link.

Current UPI Link Speed

Configures the current UPI link speed.



CPU 0 UPI Port 2

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU 0 UPI Port 2

Link Disable [No]

UPI VNA Credit Overrid 7f

Current UPI Link Speed [Auto]

UPI Link Disable

---: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Disable

Enables or disables the UPI link.

Current UPI Link Speed

Configures the current UPI link speed.

CPU 1 UPI Port 0

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU 1 UPI Port 0

Link Disable [No]

UPI VNA Credit Overrid 7f

Current UPI Link Speed [Auto]

UPI Link Disable

---: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Disable

Enables or disables the UPI link.

Current UPI Link Speed

Configures the current UPI link speed.





CPU 1 UPI Port 1

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU 1 UPI Port 1

Link Disable [No]
UPI VNA Credit Overrid 7f
Current UPI Link Speed [Auto]

UPI Link Disable

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Disable
Enables or disables the UPI link.

Current UPI Link Speed
Configures the current UPI link speed.

CPU 1 UPI Port 2

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

CPU 1 UPI Port 2

Link Disable [No]
UPI VNA Credit Overrid 7f
Current UPI Link Speed [Auto]

UPI Link Disable

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit


Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Disable
Enables or disables the UPI link.

Current UPI Link Speed
Configures the current UPI link speed.




Memory Configuration



Memory Frequency

Configures the maximum frequency of the memory. Do not select Reserved.


Memory Topology



Detects and displays the information on the memory installed.



I/O Configuration




Socket0 Configuration and Socket1 Configuration
Enters the Socket0 and Socket1 Configuration submenu.

IOAT Configuration
Enters the IOAT Configuration submenu.

I/O General Configuration
Enters the I/O General Configuration submenu.

Intel. VT for Directed I/O (VT-d)
Enters the Intel® VT for Directed I/O (VT-d) submenu.

Socket0 Configuration



IOU0 (I/O PCIe Br1)
Port Bifurcation settings for IOU 0.

IOU1 (I/O PCIe Br2)
Port Bifurcation settings for IOU 1.

IOU2 (I/O PCIe Br3)
Port Bifurcation settings for IOU 2.

I/O Redriver Control
Configures the redriver options for I/O0.



Socket 0 PcieBr0D00F0 - Port 0/DMI

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 0 PcieBr0D00F0 - Port 0/DMI

Link Speed

Override Max Link Width

PCI-E Port DeEmphasis

PCI-E Port Link Status

PCI-E Port Link Max

PCI-E Port Link Speed

PCI-E Port Max Payload

[Auto]

[Auto]

[-6.0 dB]

Linked as x4

Max Width x4

Gen 3 (8.0 GT/s)

[256B]

Choose Link Speed for this PCIe port

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.

Socket 0 PcieBr1D00F0 - Port 1A

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 0 PcieBr1D00F0 - Port 1A

PCI-E Port

Link Speed

Override Max Link Width

PCI-E Port DeEmphasis

PCI-E Port Link Status

PCI-E Port Link Max

PCI-E Port Link Speed

PCI-E Port Max Payload

[Enable]

[Auto]

[Auto]

[-6.0 dB]

Linked as x16

Max Width x16

Gen 3 (8.0 GT/s)

[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.





Socket 0 PcieBr2D00F0 - Port 2A

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 0 PcieBr2D00F0 - Port 2A

PCI-E Port

Link Speed

Override Max Link Widt

PCI-E Port DeEmphasis

PCI-E Port Link Status

PCI-E Port Link Max

PCI-E Port Link Speed

PCI-E Port Max Payload

[Enable]

[Auto]

[Auto]

[-6.0 dB]

Link Did Not Train

Max Width x8

Link Did Not Train

[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.

Socket 0 PcieBr2D02F0 - Port 2C

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 0 PcieBr2D02F0 - Port 2C

PCI-E Port

Link Speed

Override Max Link Widt

PCI-E Port DeEmphasis

PCI-E Port Link Status

PCI-E Port Link Max

PCI-E Port Link Speed

PCI-E Port Max Payload

[Enable]

[Auto]

[Auto]

[-6.0 dB]

Link Did Not Train

Max Width x8

Link Did Not Train

[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.



Socket 0 PcieBr3D00F0 - Port 3A

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 0 PcieBr3D00F0 - Port 3A

PCI-E Port

Link Speed

Override Max Link Widt

PCI-E Port DeEmphasis

PCI-E Port Link Status

PCI-E Port Link Max

PCI-E Port Link Speed

PCI-E Port Max Payload

[Enable]

[Auto]

[Auto]

[-6.0 dB]

Link Did Not Train

Max Width x8

Link Did Not Train

[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.

Socket 0 PcieBr3D02F0 - Port 3C

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 0 PcieBr3D02F0 - Port 3C

PCI-E Port

Link Speed

Override Max Link Widt

PCI-E Port DeEmphasis

PCI-E Port Link Status

PCI-E Port Link Max

PCI-E Port Link Speed

PCI-E Port Max Payload

[Enable]

[Auto]

[Auto]

[-6.0 dB]

Link Did Not Train

Max Width x8

Link Did Not Train

[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis


Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.



Socket1 Configuration




IOU0 (IIO PCIe Br1)

Port Bifurcation settings for IOU 0.

IOU1 (IIO PCIe Br2)

Port Bifurcation settings for IOU 1.

Socket 1 PCIe Br1D00F0 - Port 1A



PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.



Socket 1 PcieBr1D02F0 - Port 1C

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 1 PcieBr1D02F0 - Port 1C

PCI-E Port
Link Speed
Override Max Link Widt
PCI-E Port DeEmphasis
PCI-E Port Link Status
PCI-E Port Link Max
PCI-E Port Link Speed
PCI-E Port Max Payload

[Enable]
[Auto]
[Auto]
[-6.0 dB]
Link Did Not Train
Max Width x8
Link Did Not Train
[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.

Socket 1 PcieBr2D00F0 - Port 2A

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Socket 1 PcieBr2D00F0 - Port 2A

PCI-E Port
Link Speed
Override Max Link Widt
PCI-E Port DeEmphasis
PCI-E Port Link Status
PCI-E Port Link Max
PCI-E Port Link Speed
PCI-E Port Max Payload

[Enable]
[Auto]
[Auto]
[-6.0 dB]
Link Did Not Train
Max Width x8
Link Did Not Train
[256B]

In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.

PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.


Copyright © 2019 NEXCOM International Co., Ltd. All Rights Reserved.

67

NSA 7146 User Manual



Socket 1 PcieBr2D02F0 - Port 2C



PCI-E Port

Enables or disables the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space.

Link Speed

Configures the link speed for the PCIe port.

Override Max Link Width

Configures the link speed to override the max link width set by bifurcation.


PCI-E Port DeEmphasis

Configures the de-emphasis control for the PCIe port.

PCI-E Port Max Payload

Configures the PCIe port maximum payload size.

IOAT Configuration




Sck0 IOAT Config and Sck1 IOAT Config

Enters the Socket0 and Socket1 IOAT Configuration submenu.




Sck0 IOAT Config



DMA
Enables or disables DMA.

No Snoop
Enables or disables No Snoop function for each CB device.



Sck0 IOAT Config Cont.

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

DMA

No Snoop

IOAT Function 5 Items

DMA

No Snoop

IOAT Function 6 Items

DMA

No Snoop

IOAT Function 7 Items

DMA

No Snoop

[Enable]

[Disable]

[Enable]

[Disable]

[Enable]

[Disable]

[Enable]

[Disable]

[Enable]

[Disable]

No Snoop Enable/Disable for each CB device

----- Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

- DMA**
Enables or disables DMA.
- No Snoop**
Enables or disables No Snoop function for each CB device.

Sck1 IOAT Config

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

IOAT Function 0 Items

DMA

No Snoop

IOAT Function 1 Items

DMA

No Snoop

IOAT Function 2 Items

DMA

No Snoop

IOAT Function 3 Items

[Enable]

[Disable]

[Enable]

[Disable]

[Enable]

[Disable]

[Enable]

[Disable]


Select Dma Enable/Disable for each CB device

----- Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.


- DMA**
Enables or disables DMA.
- No Snoop**
Enables or disables No Snoop function for each CB device.

Sck1 IOAT Config Cont.




DMA
Enables or disables DMA.

No Snoop
Enables or disables No Snoop function for each CB device.






I/O General Configuration



I/O IOAPIC Stack 0 to I/O IOAPIC Stack 5

Enables or disables I/O Advanced Power Interface Configuration (IOAPIC) for Stack 0 to Stack 5 of Socket 0 and Socket 1.


Intel. VT for Directed I/O (VT-d)



Intel. VT for Directed I/O

Enables or disables Intel® Virtualization Technology for Directed I/O (VT-d) by reporting the I/O device assignment to VMM through DMAR ACPI tables.

Advanced Power Management Configuration




CPU P State Control

Enters the CPU P State Control submenu.

Hardware PM State Control

Enters the Hardware PM State Control submenu.

CPU P State Control



SpeedStep (Pstates)

Enables or disables Intel® SpeedStep technology.



Hardware PM State Control

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Socket Configuration

Hardware PM State Control

Hardware P-States [Disable]

Disable: Hardware chooses a P-state based on OS Request (Legacy P-States)
Native Mode: Hardware chooses a P-state based on OS guidance Out of Band

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Hardware P-States

Disable	Hardware chooses a P-state based on OS Request. (Legacy P-States).
Native Mode	Hardware chooses a P-state based on OS guidance.
Out of Band Mode	Hardware autonomously chooses a P-state (no OS guidance).

Server Mgmt

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

MainAdvancedPlatform ConfigurationSocket ConfigurationServer Mgmt

BMC Self Test Status PASSED

BMC Device ID 32

BMC Device Revision 1

BMC Firmware Revision 1.01

IPMI Version 2.0

BMC Interface(s) KCS, USB

BMC Support [Enabled]

▶ System Event Log

▶ BMC network configuration

▶ View System Event Log

▶ BMC User Settings

BMC Warm Reset

Enable/Disable interfaces to communicate with BMC

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

BMC Support

Enables or disables interfaces to communicate with BMC.

BMC Warm Reset

To perform a BMC warm reset, select this field then press <Enter>.





System Event Log

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

Enabling/Disabling Options

SEL Components

[Enabled]

Erasing Settings

Erase SEL

[No]

When SEL is Full

[Do Nothing]

Custom EFI Logging Options

Log EFI Status Codes

[Error code]

NOTE: All values changed here do not take effect until computer is restarted.

Change this to enable or disable event logging for error/progress codes during boot.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

SEL Components

Enables or disables event logging for error/progress codes during boot.

Erase SEL

Configures the options for erasing SEL.

When SEL is Full

Configures the action to perform when SEL is full.

Log EFI Status Codes

Configures the options for logging EFI status codes.

BMC Network Configuration

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

--BMC network configuration--

Configure IPV4 support

Lan channel 1

Configuration Address

[Unspecified]

Current Configuration

DynamicAddressBmcDhcp

Station IP address

0.0.0.0

Subnet mask

0.0.0.0

Station MAC address

00-50-20-75-23-01

Router IP address

0.0.0.0

Router MAC address

00-00-00-00-00-00

Lan channel 2

Configuration Address

[Unspecified]

Current Configuration

DynamicAddressBmcDhcp

Station IP address

0.0.0.0

Select to configure LAN channel parameters statically or dynamically (by BIOS or BMC). Unspecified option will not modify any BMC network parameters during BIOS phase

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Configuration Address

Select to configure LAN channel parameters statically or dynamically (by BIOS or BMC). Unspecified option will not modify any BMC network parameters during BIOS phase.

BMC Network Configuration Cont.

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

Lan channel 2

Configuration Address

Current Configuration

Station IP address

Subnet mask

Station MAC address

Router IP address

Router MAC address

Configure IPv6 support

[Unspecified]

DynamicAddressBmcDhcp

0.0.0.0

0.0.0.0

00-50-20-75-23-02

0.0.0.0

00-00-00-00-00-00

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Lan channel 1

IPv6 Support

Configuration Address

[Enabled]

[Unspecified]

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

IPv6 Support (LAN Channel 1)
Enables or disables IPv6 support for LAN channel 1.

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

Configuration Address

Current Configuration

Station IPv6 address

Prefix Length

IPv6 Router1 IP Address

IPv6 address status

IPv6 DHCP Algorithm

Lan channel 2

IPv6 Support

[Unspecified]

DynamicAddressBmcDhcp

::

0

::

Active

DHCPv6

[Enabled]

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.



BMC Network Configuration Cont.

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

Lan channel 2

IPv6 Support

[Enabled]

Configuration Address

[Unspecified]

Current Configuration

DynamicAddressBmcDhcp

Station IPv6 address

::

Prefix Length

0

IPv6 Router1 IP Address

::

IPv6 address status

Active

IPv6 DHCP Algorithm

DHCPv6

Select to configure LAN channel parameters statically or dynamically (by BIOS or BMC). Unspecified option will not modify any BMC network parameters during BIOS phase

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

IPv6 Support (LAN Channel 2)
Enables or disables IPv6 support for LAN channel 2.

View System Event Log

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

No. of log entries in SEL : 3640

DATE	TIME	SENSOR TYPE
01/01/00	08:00:14	Fan
01/01/00	08:00:14	Fan
01/01/00	08:00:15	Fan
01/01/00	08:00:15	Fan
01/01/00	08:00:15	Fan
01/01/00	08:00:15	Fan
04/24/19	11:52:50	System Boot/Restart In...
04/24/19	11:52:50	Fan
04/24/19	11:52:50	Fan
04/24/19	11:52:50	Fan
04/24/19	11:52:50	Fan
04/24/19	11:52:50	Fan
04/24/19	11:52:51	Fan

HEX:
01 00 02 0E B4 6D
38 20 00 04 04 0E
01 50 00 22
Generator ID: BMC - LUN
#0 (Channel #0)
Sensor Number: 0x0E
Power System Board

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Displays system event log information including date, time and sensor type.





BMC User Settings

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

BMC User Settings

► Add User

► Delete User

► Change User Settings

Press <Enter> to Add a User.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Add User

Option to add a user.

Delete User

Option to delete a user.

Change User Settings

Option to change user settings.

Add User

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

BMC Add User Details

User Name

User Password

User Access

Channel No

User Privilege Limit

[Disable]

0

[Reserved]

Enter BMC User Name

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

User Name and User Password

Configures the login username and password of the BMC user account.

Channel No and User Privilege Limit

Configures the BMC channel number and account access rights.



Delete User

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

BMC Delete User Details

User Name

User Password

Enter BMC User Name

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

User Name and User Password

Specify the login username and password of the BMC user account to delete.

Change User Settings

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Server Mgmt

BMC Change User Settings

User Name

User Password

Change User Password

User Access

Channel No

User Privilege Limit

[Disable]

0

[Reserved]

Enter BMC User Name

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

User Name and User Password

Enter the login username and password of the BMC user account that needs to be changed.

Change User Password

Reconfigures a new password for the account.

User Access

Enables or disables this account.

Channel No and User Privilege Limit

Reconfigures the BMC channel number and account access rights.





Security

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Security

Boot

Save & Exit

Password Description

If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. The password length must be in the following range:

Minimum length

3

Maximum length

20

Administrator Password

Set Administrator Password

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Administrator Password

Select this to reconfigure the administrator’s password.

Boot

Aptio Setup Utility - Copyright (C) 2019 American Megatrends, Inc.

Security

Boot

Save & Exit

Boot Configuration

Setup Prompt Timeout

1

Bootup NumLock State

[On]

Quiet Boot

[Disabled]

AMI Virtual Devices

[Disable]

Boot mode select

[LEGACY]

FIXED BOOT ORDER Priorities

Boot Option #1

[Hard Disk]

Boot Option #2

[CD/DVD]

Boot Option #3

[USB Hard Disk]

Boot Option #4

[USB CD/DVD]

Boot Option #5

[USB Key:KingstonD. . .]

Boot Option #6

[USB Floppy]

Boot Option #7

[USB Lan]

Boot Option #8

[Network]

Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.20.1275. Copyright (C) 2019 American Megatrends, Inc.

Setup Prompt Timeout

Configures the number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.

Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.





Quiet Boot

- Enabled Displays OEM logo instead of the POST messages.
- Disabled Displays normal POST messages.

AMI Virtual Devices

Enables or disables AMI virtual devices.

Boot mode select

Configures the boot mode option.

FIXED BOOT ORDER Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.

Save & Exit



Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes and Reset

To exit the Setup utility and reset without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Launch EFI Shell from Filesystem Device

To launch EFI shell from a filesystem device, select this field and press <Enter>.

