



Quick reference guide is subject to change without prior notice. For any update, please visit our website:

www.nexcom.com
 *=Default

CN1/CN2: Keyboard connector (SBC to backplane)

PW1: Power Connector

1	+12V
2	GND
3	GND
4	+5V

CN6: ATX P/S Control connector

1	+5VSB
2	GND
3	PS-ON

CN7: AT Power Connector

CN9: ATX Power Connector

KK1: System Keyboard connector

CN3/CN4: Chassis Fan

CN8: Terminal Block

1	GND
2	+12V
3	-12V
4	VCC
5	-5V